

DVD PLAYER


DVD-V7200

Operating Instructions (Basic Operations)

NTSC

Thank you for buying this Pioneer product.
Please read through these operating instructions to learn how to correctly operate your DVD-V7200 player. After you have finished reading the instructions, put them away in a safe place for future reference.

Before operating your unit, please refer to page 8 "Before Using" and page 44 - 48 "Connecting the player."



IMPORTANT



The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.

CAUTION

RISK OF ELECTRIC SHOCK
DO NOT OPEN

CAUTION:
TO PREVENT THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

IMPORTANT SAFETY INSTRUCTIONS

READ INSTRUCTIONS — All the safety and operating instructions should be read before the product is operated.

RETAIN INSTRUCTIONS — The safety and operating instructions should be retained for future reference.

HEED WARNINGS — All warnings on the product and in the operating instructions should be adhered to.

FOLLOW INSTRUCTIONS — All operating and use instructions should be followed.

CLEANING — Unplug this product from the wall outlet before cleaning. The product should be cleaned only with a polishing cloth or a soft dry cloth. Never clean with furniture wax, benzene, insecticides or other volatile liquids since they may corrode the cabinet.

ATTACHMENTS — Do not use attachments not recommended by the product manufacturer as they may cause hazards.

WATER AND MOISTURE — Do not use this product near water — for example, near a bathtub, wash bowl, kitchen sink, or laundry tub; in a wet basement; or near a swimming pool; and the like.

ACCESSORIES — Do not place this product on an unstable cart, stand, tripod, bracket, or table. The product may fall, causing serious injury to a child or adult, and serious damage to the product. Use only with a cart, stand, tripod, bracket, or table recommended by the manufacturer, or sold with the product. Any mounting of the product should follow the manufacturer's instructions, and should use a mounting accessory recommended by the manufacturer.

CART — A product and cart combination should be moved with care. Quick stops, excessive force, and uneven surfaces may cause the product and cart combination to overturn.



VENTILATION — Slots and openings in the cabinet are provided for ventilation and to ensure reliable operation of the product and to protect it from overheating, and these openings must not be blocked or covered. The openings should never be blocked by placing the product on a bed, sofa, rug, or other similar surface. This product should not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided or the manufacturer's instructions have been adhered to.

POWER SOURCES — This product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply to your home, consult your product dealer or local power company.

LOCATION — The appliance should be installed in a stable location.

NONUSE PERIODS — The power cord of the appliance should be unplugged from the outlet when left unused for a long period of time.

GROUNDING OR POLARIZATION

If this product is equipped with a polarized alternating current line plug (a plug having one blade wider than the other), it will fit into the outlet only one way. This is a safety feature. If you are unable to insert the plug fully into the outlet, try reversing the plug. If the plug should still fail to fit, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the polarized plug.

If this product is equipped with a three-wire grounding type plug, a plug having a third (grounding) pin, it will only fit into a grounding type power outlet. This is a safety feature. If you are unable to insert the plug into the outlet, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the grounding type plug.

POWER-CORD PROTECTION — Power-supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to cords at plugs, convenience receptacles, and the point where they exit from the product.

OUTDOOR ANTENNA GROUNDING — If an outside antenna or cable system is connected to the product, be sure the antenna or cable system is grounded so as to provide some protection against voltage surges and built-up static charges. Article 810 of the National Electrical Code, ANSI/NFPA 70, provides information with regard to proper grounding of the mast and supporting structure, grounding of the lead-in wire to an antenna discharge unit, size of grounding conductors, location of antenna-discharge unit, connection to grounding electrodes, and requirements for the grounding electrode. See Figure A.

LIGHTNING — For added protection for this product during a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect the antenna or cable system. This will prevent damage to the product due to lightning and power-line surges.

POWER LINES — An outside antenna system should not be located in the vicinity of overhead power lines or other electric light or power circuits, or where it can fall into such power lines or circuits. When installing an outside antenna system, extreme care should be taken to keep from touching such power lines or circuits as contact with them might be fatal.

OVERLOADING — Do not overload wall outlets, extension cords, or integral convenience receptacles as this can result in a risk of fire or electric shock.

OBJECT AND LIQUID ENTRY — Never push objects of any kind into this product through openings as they may touch dangerous voltage points or short-out parts that could result in a fire or electric shock. Never spill liquid of any kind on the product.

SERVICING — Do not attempt to service this product yourself as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.

DAMAGE REQUIRING SERVICE — Unplug this product from the wall outlet and refer servicing to qualified service personnel under the following conditions: When the power-supply cord or plug is damaged. If liquid has been spilled, or objects have fallen into the product.

If the product has been exposed to rain or water. If the product does not operate normally by following the operating instructions. Adjust only those controls that are covered by the operating instructions as an improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the product to its normal operation.

If the product has been dropped or damaged in any way.

When the product exhibits a distinct change in performance — this indicates a need for service.

REPLACEMENT PARTS — When replacement parts are required, be sure the service technician has used replacement parts specified by the manufacturer or have the same characteristics as the original part. Unauthorized substitutions may result in fire, electric shock, or other hazards.

SAFETY CHECK — Upon completion of any service or repairs to this product, ask the service technician to perform safety checks to determine that the product is in proper operating condition.

WALL OR CEILING MOUNTING — The product should not be mounted to a wall or ceiling.

HEAT — The product should be situated away from heat sources such as radiators, heat registers, stoves, or other products (including amplifiers) that produce heat.




Fig. A

NEC — NATIONAL ELECTRICAL CODE

WARNING: TO PREVENT FIRE OR SHOCK HAZARD, DO NOT EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE.

THE POWER SWITCH IS SECONDARY CONNECTED AND THEREFORE DOES NOT SEPARATE THE UNIT FROM MAINS POWER IN STANDBY POSITION.

CAUTION: This product satisfies FCC regulations when shielded cables and connectors are used to connect the unit to other equipment. To prevent electromagnetic interference with electric appliances such as radios and televisions, use shielded cables and connectors for connections.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Information to User

Alteration or modifications carried out without appropriate authorization may invalidate the user's right to operate the equipment.

CAUTION

Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.
The use of optical instruments with this product will increase eye hazard.

[For Canadian model]

This Class B digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.

[Pour le modèle Canadien]

Cet appareil numérique de la Classe B respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

Note to CATV system installer

This reminder is provided to call the CATV system installer's attention to Article 820-40 of the NEC that provides guidelines for proper grounding and, in particular, specifies that the cable ground shall be connected to the grounding system of the building, as close to the point of cable entry as practical.

**FEDERAL COMMUNICATIONS COMMISSION
DECLARATION OF CONFORMITY**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Product Name: DVD player

Model Number: DVD-V7200

Product Category: Class B Personal Computers & Peripherals

Responsible Party Name: PIONEER ELECTRONICS SERVICE, INC.

Address: 1925 E. DOMINGUEZ ST. LONG BEACH, CA 90810 U.S.A.

Phone/Fax Number: (310) 952-2359 / (310) 952-2412

This product is equipped with technology for the protection of copyrights protected by U.S. patent claims and other intellectual property rights possessed by the Macrovision Corporation and other rights holders. Special permission from Macrovision Corporation is required for the use of this copyright-protection technology, and that permission has been received for home use and certain other limited applications. Reverse engineering and disassembly of this technology are prohibited.

Component Features and Functions

1. High-Reliability, High-Endurance Player

This player features a high-performance brushless spindle motor. Mechanical components have been sealed against heat and dust, giving this unit improved reliability.

2. Half-Rack Size (210 mm width)

The half-width size makes it possible to mount two players side-by-side in a single rack installation.

3. Large Remote Control Unit (wired/wireless)

A large, easy-to-use remote control that is similar to ones found with LD (laser disc) players is included.

4. Frame Search Function

For the first time on a DVD player, a frame search option is available. (Basic Operations: page 22)

5. DVD Barcode Function (laser bar code)

The laser bar code system used with LD players has been increased to include the DVD technology. The same scanners used previously used will work with a DVD disc barcode.

6. Barcode Stack/Command Stack Function

Previous players were unable to use remote control commands and bar codes to record data as-is onto the program area. Once control commands and bar codes are input, this player quickly and easily switches between successive images allowing more convenient displays demonstrations.

(Advanced Feature Operations: page 25)

7. Video Blackboard Function

Graphics and characters can be recorded at desired places on the DVD video. The recorded graphics and characters then appear automatically during playback allowing you to compose more effective demonstrations and presentations.

(Advanced Feature Operations: page 17)

8. Mouse Control*

Instead of just the remote control, a PS/2 pointing device can be used to control the player as well. This allows selecting specific locations by the point-and-click method.

(Advanced Feature Operations: page 6)

9. Weekly Timer / Power-On Start Function*

This function allows the user to set desired daily power on/off times and the starting image title. This function can also be used in conjunction with the barcode/command stack to allow programmed playback.

10. External Control Function (RS-232C, external option switch)

Equipped with RS-232C commands compatible with LD (laser disc) protocol, and also supporting DVD, video CD, and CD playback. An additional external connection switch terminal is also provided for connections other than to RS-232C interface connectors. By connecting a switch to this terminal, direct selection can be made of DVD video menu selections and barcode/command stack commands.

11. External Sync Input

This terminal allows output of video signals linked to an external sync signal.

(Advanced Feature Operations: page 45)

12. Hyper Video

Using a mouse, the user may access related video segments by simply clicking on transparent video object buttons that were created by the disc title developers.

13. Dolby Digital*

Connect to a Digital Surround Amp and Surround Processor for 5.1ch Dolby Digital Surround entertainment.

14. GUI Operation

While viewing Pioneer's original GUI on-screen displays, you can control the player with a remote control. Even discs without a recorded menu can still perform GUI operation through the player-provided menu.

(Basic Operations: page 31)

15. Still Frame, Slow Play, Single Frame Advance*

You can view still frames, do slow play and advance one frame at a time.

(Basic Operations: page 24)

16. Repeat Play*

Wide range of Repeat Play possibilities.

(Basic Operations: page 23)

17. Multilingual Subtitles*

You can select different subtitle languages when watching movies and other videos.

(Basic Operations: page 29)

18. Multi-Angle*

This feature lets scenes be viewed from different angles.

(Basic Operations: page 29)

19. Multiple Languages*

With discs that have multiple language soundtracks, you can select between the different languages.

(Basic Operations: page 28)

20. Parental Level*

Lets you select a "parental level" (user restriction level) to prevent children viewing undesirable material.

(Basic Operations: page 38)

21. PBC Video CD Compatibility

Supports playback of Video CDs (Version 2.0) with PBC (Play Back Control). There are two types of playback possible depending upon the disc.

* This feature may not be possible with all discs.

Contents

Basic Operation

- Playing DVDs, CDs and Video CDs
- Chapter (Track) Skip Forward/Skip Back
- Stopping Playback & Switching Power OFF
- Playback by Menu Selection
- Searching for a Desired Scene (SEARCH)
- Repeat Play
- Still Frame/Slow Play/Frame Advance

Setting

- Multi-Aspect Setting for Wide Screen TV Software
- Selecting a Desired Background Color
- Selecting Languages (Multi-Language)
- Changing Audio Type
- Selecting Subtitle Language (Multi-Language Subtitles)
- Viewing from a Desired Camera Angle (Multi-Angle)
- Viewing Disc Information
- Outline of GUI (Graphical User Interface) Operation
- Changing Settings
- How to Set Basic Audio and Subtitles.

Set-Up

- Connecting the Player
 - Connection example 1. ● Television (monitor TV) ● Control ● Com
 - Connection example 2. AV amplifier with digital input for Dolby Dig
 - Connection example 3. AV amp
 - Connection example 4. Digital recording components
- About the Interface Connector
- Using a LaserBarcode Scanner (Sold Separately)

Other Information

- For Proper and Long Use
- Troubleshooting
- Terms
- Specifications

Advanced Feature Operations

- Proper setting items to the industrial players menu
- Weekly Timer function operation/display specifications
- POWER ON START function
- How to display the play time and power ON time
- Player control using mouse
- Character input/picture drawing
- Executing a video blackboard
- Barcode/Command Stack function
- Barcode/Command Stack Setting
- Using a Barcode/Command Stack


See the provided Advanced Feature Operations manual for information about advanced operations.

Page		Applicable discs			
		DVD	CD	VIDEO CD	
					
	16	●	●	●	Basic Operation
	17	●	●	●	
	18	●	●	●	
	19	●	●	●	
	20	●	●	●	
	23	●	●	●	
	24	●		●	
	26	●			Setting
	27	●	●	●	
	28	●			
	28		●	●	
	29	●			
	29	●			
	30	●	●	●	
	31	●	●	●	
	37	●	●	●	
	40	●			
Computer ● Sync Generator	45				Set-Up
Digital (AC-3)	47				
	48				
	48				
	49				Other Information
	50				
	51				
	52				Advanced Feature Operations (separate manual)
	53				
(Page in Advanced Feature Operations manual)	3				
	4				
	8				
	10				
	11				
	12				
	22				
	24				
	25				
	36				


Before Using

Check accessories


Audio cord




Video cord



Remote control unit



Batteries....2
(AA/R6P)




Other included items:

- Laser bar-code sheet
- RF adaptor set clamp
- Screw
- Warranty card
- Operating Instructions (Basic Operations and Advanced Feature Operations)


Inserting batteries into the remote control

1



While pressing the back cover, pull out in the direction indicated by the arrow.


2



Insert batteries.

Make sure to match the plus (+) and minus (-) polarity guides on the batteries with the marks inside the battery compartment.

3



Close the cover.

Note

- ◆ Do not mix old and new batteries.
- ◆ Even batteries of the same type will differ in voltage. Avoid mixing different type of batteries together.
- ◆ When not using the remote control for a long period of time (over 1 month), remove the batteries to avoid possible damage from battery corrosion. If battery leakage occurs, wipe the battery liquid from the battery, then insert new batteries.

Precautions Regarding Use

Installation

- Install the player in a level and stable location.
Do not use in unbalanced locations, or locations exposed to too much vibration.
- Do not hinder the player's cooling functions. Avoid placing on long-pile carpets, etc. Also do not wrap or cover with towels or cloths when in use. Such coverings can impede the player's cooling function and result in internal damage.
- Do not place objects on top of the player.
- Install in a location which is not exposed to heat sources. Avoid installing the player above an amplifier or other heat-emitting component. If installing the player in a component rack, select a rack with good ventilation and , located well below the amplifier.

Operating Environment

Operating environment temperature and humidity:
+5°C ~ +35°C; less than 85% RH (cooling vents not blocked)

- Do Not Install in the Following Locations:
 - exposed to direct sunlight or strong artificial light
 - exposed to dust or smoke
 - subject to vibration
 - subject to strong electro-magnetic fields
 - near sources of heat
 - exposed to high levels of electronic noise
 - subject to electrostatic noise
 - exposed to high humidity, or poor ventilation

Condensation

Moisture will form in the operating section of the player if the player is brought from cool surroundings into a warm room or if the temperature of the room rises suddenly. When this happens, the player's performance may be impaired.

To prevent this, let the player stand in its new surroundings for about an hour before switching it on, or make sure that the room temperature rises gradually.

Condensation may also form during the summer if the player is exposed to the breeze from an air conditioner. In such cases, change the location of the player.



Moving the Player

When transporting this player to a new location, be sure to use the packaging provided and avoid subjecting the player to vibration, shock, or dropping. During transport, protect the player from exposure to heat or water.

Before packaging the player, remove any disc loaded, since moving the player with a loaded disc may cause damage to the disc or player's internal parts.

SPECIAL PRECAUTIONS!

Never attempt to move the player while a disc is playing. Discs rotate at very high speeds, and lifting or moving a player at such times could cause damage to the disc. Subjecting the player to strong impact or vibration when a disc is loaded may cause damage to a disc or the player. Be sure the player is stopped and no discs are loaded before moving the player. Verify that the disc tray is empty before lifting the player. This component is built using precision optical parts. Take care to control temperature and dust inside the room where this player is installed.

- When installing this player for use in a stereo component rack, consider a rack that prevents temperature buildup. Avoid blocking the cooling vents on the top and bottom of player. When using a rack mount, certain conditions must be met regarding attachment of the unit. Please consult your nearest Pioneer dealer for details before installing.
- When multiple players are connected in parallel, a high surge current will be passed through the units when the power is first turned on. Please consult your Pioneer dealer regarding ratings to select the appropriate power switch.

Disc Types Compatible with This

This player is DVD, CD and Video CD compatible. The marks shown on the right are found on disc labels or on disc jackets.

- This player can play all discs bearing the marks on the right without the need for an adaptor.
- To prevent malfunction, avoid using an 8 cm (3 inch) adaptor when playing CDs.


This unit is NTSC compatible (U.S. and Canadian TV system). You cannot play discs other than those shown on the right.

* During DVD playback, the data transfer rate is at 4.7 MB per second.

Handling the discs

Holding with both hands	
Holding with one hand	

Disc Table



Types of playable discs and their marks	Diameter/Playable sides	Playback time
DVD VIDEO 	DVD VIDEO*	Digital audio Digital video (MPEG 2)
	12 cm (5in.)/single-sided	1 layer 2 layer
	12 cm (5in.)/double-sided	1 layer 2 layer
	DVD VIDEO*	Digital audio Digital video (MPEG 2)
VIDEO CD 	VIDEO CD	Digital audio Digital video (MPEG 1)
	12 cm (5 in.)/single-sided	Max. 74 minutes
	VIDEO CD single	Digital audio Digital video (MPEG 1)
	8 cm (3 in.)/single-sided	Max. 20 minutes
CD 	CD	Digital audio Max. 74 minutes
	12 cm (5 in.)/single-sided	
	CD single	Digital audio Max. 20 minutes
	8 cm (3 in.)/single-sided	

To avoid damage etc., do not play any discs other than those indicated above.

Ex: DVD-Audio, DVD-ROM, CD-ROM, CD-R etc...

Note

- ◆ To play a DVD disc, the Region number on the disc and on the player's rear panel must match. (refer to "Terms" on page 54)
- ◆ Depending on the kind of DVD used, the special functions of this player (control via mouse, video blackboard, bar-code stack and stack command, etc.) may not operate fully. These functions are designed to operate primarily with DVD, but only a single feature may function with CDs or video CDs.

Disc Types Compatible with This Unit

CARE OF DISCS

How to hold discs


When loading or removing discs, try not to touch the playing surface.



Cleaning


Fingerprints or other dirt on the disc may affect sound and picture quality.

To clean your discs, use a soft clean cloth to wipe them. If necessary, moisten a soft cloth with diluted neutral detergent to remove heavy dirt or fingerprints.



Do not wipe in a circular motion!

(Concentric scratches in the disc groove tend to cause noise)




Gently wipe from the inside edge toward the outer edge.

Discs must not be cleaned with record cleaning sprays, static prevention sprays, etc. or volatile liquids such as benzine or thinner, etc.

NEVER PLAY CRACKED OR WARPED DISCS

- A disc during playback revolves at high speeds. Never play a cracked, scratched or warped disc. This may damage the player or cause it to malfunction.



After using discs, store them upright

After playing a disc, always remove it from the player and return it to its jacket. Then store it standing upright away from heat and humidity.

- Store discs carefully. If you store discs at an angle, or stacked on top of each other, discs may become warped even when in their jackets.
- Do not leave discs in locations such as the seat of a car or glovebox which may become excessively hot.

CAUTION WHEN USING THE DISC

All rights reserved.

Unauthorized public performance, broadcasting or copying is a violation of applicable laws.

CLEANING CARE


Use a soft, dry cloth for cleaning. For stubborn dirt, soak the cloth in a weak detergent solution, wring well, then wipe. Use a dry cloth to buff it dry. Do not use any volatile agents such as benzine or paint thinner as they may damage the player case or surface.

Lens cleaner

The player's pickup lens should not become dirty in normal use. If it should malfunction due to dust or grime, please contact the nearest PIONEER authorized service center. Lens cleaners are commercially available but special care should be exercised since some can cause damage to the lens.

Never use CD's with special shapes.


CD's with special shapes (heart-shaped CDs, octagonal CDs, etc.) cannot be played on this set. Attempting to play an odd shaped disc may damage the player and the disc.



Names and Functions


Remote control unit

Function button is not pressed so the light is off




Function button pressed (indicator light on)

If no button is pressed, the indicator automatically goes out after 30 seconds.




The letters on the buttons are used to enter characters when required by a disc. See the section "Entering Characters" in the Advanced Feature Operations manual.

Front panel



Rear panel

Your amp	Regular AV amp	Select PCM from the menu
	AC-3 compatible amp	Select PCM/DOLBY DIGITAL from the menu




Names and Functions

Remote control operation

Wireless Remote Operation


When operating the remote control, point it at the remote sensor located on the player's front panel. The remote control can be used up to 23 feet (7 m) from the player and within a 30° angle each side of the sensor.

* Exposing the remote sensor to direct sunlight or strong light may cause faulty operation.




Wired Operation

Use a commercially available mini-plug connector cord to link the player's external control jack (EXT. CONT) to the remote control.




Basic Operation

Playing DVDs, CDs and Video CDs.....	16
Chapter (Track) Skip Forward/Skip Back.....	17
Stopping Playback & Switching Power OFF	18
Playback by Menu Selection	19
Searching for a Desired Scene (SEARCH)	20
Repeat Play	23
Still Frame/Slow Play/Frame Advance	24



Playing DVDs, CDs and Video CDs


1



Press the button

- The player's STANDBY indicator changes from orange (Power OFF) to green (Power ON).


2



Press the button

- The disc table comes out.

3




Load a disc

- Load a disc with the label side facing up, using the disc table guide to align the disc.

Note


- ◆ DVD disc region codes must match the region number on the player (refer to the "Terms" section on page 54). This player is coded for region 1.
 - ◆ Only DVD VIDEO discs, Video CDs and CDs can be played back.
 - ◆ During operation, the following marks may appear on the TV screen.
- : Appears when this player cannot perform the selected function
- : Appears when the disc cannot perform the selected function

4




Press the button

- Disc table closes and playback begins.
- Press the button on the front of the player.
- Depending on the disc, a menu is displayed. Refer to page 19 when a menu is displayed.



Chapter (Track) Skip Forward/Skip

Skipping Forward to the Next Chapter (track)




Press the button



- Press to skip forward to the next chapter (track).
- The button on the front panel has the same function.

Fast Forward




Press and hold the button

Press to scan forward to a new section on the disc.

- Release the button when you reach the desired location. Normal playback resumes.
- The button on the front panel has the same function.
- When the 'SCAN' indicator on the display changes (flashing to steady), fast forward continues even if the button is released. When the desired location is reached, press the button.

Skipping Back to the Previous Chapter (track)




Press the button



- Press once to skip back to the start of the chapter (track) currently playing.
- Press again to skip back to the start of the previous chapter (track).
- The button on the front panel has the same function.



Fast Reverse



Continue pressing the button


Press and hold to scan back to a previous location on the disc.

- Release the button when you reach the desired location (normal playback resumes).
- The button on the front panel has the same function.
- When the "SCAN" indicator on the screen changes from flashing to lit, fast rewind will continue even if the button is released. When the desired location has been reached, press the button.



Stopping Playback & Switching


FUNCTION indicator



Press the **FUNCTION** button, then press the **▶/■** button while the **FUNCTION** indicator is lit.

- On the front panel, press and playback stops


2



Press the **STOP/OPEN/CLOSE** button


- The disc table comes out.

3




Remove the disc

4




Press the **POWER** button

- The disc table slides in, the power switches OFF, and the **STANDBY** indicator changes from green to orange.



STANDBY indicator

Playback by Menu Selection



- 1 POP
- 2 JAZZ
- 3 COUNTRY
- 4 R&B
- 5 CLASSICAL

DVDs and Video CDs often feature selection menus.

To choose a title or track, simply make a selection from a menu.

Important!

To use the number pad, press the **FUNCTION** button (the **FUNCTION** indicator must be lit)

Selection and Playback from a Menu

FUNCTION indicator

① Press

- A menu is displayed. This menu is recorded on the disc. Menus differ depending upon the disc.
- With Video CDs that have Play Back Control, PBC is listed on the screen.

- 1 POP
- 2 JAZZ
- 3 COUNTRY
- 4 R&B
- 5 CLASSICAL

② For example, to select **2 JAZZ**, press **FUNCTION** button, then press the **2** button

- When selecting a number higher than 10, use the **FUNCTION** and **>10 CLEAR** buttons. For example:

When selecting 10, press **FUNCTION** → **>10 CLEAR** → **1** → **0** → **TITLE**

- When selecting 17, press

FUNCTION → **>10 CLEAR** → **1** → **7** → **TITLE**

- When selecting 20, press

FUNCTION → **>10 CLEAR** → **2** → **0** → **TITLE**

- The selected title or track starts playing.

Tips

- Menu details differ depending on the disc. Play a disc by making menu selections combining direction buttons (, , ,), ENTER button () and number(s)
- You can also play Video CDs without calling up a menu by pressing a number button during STOP. For example, to start playback from track 1, press the **1** button.

Returning to Menu Display During Playback

During DVD playback

① Press **TITLE** button

② Press **MENU** button

- Press **MENU** again for the Titles menu then follow the screen prompts

During Video CD playback

Press **RETURN** button


Pressing the **RETURN** button during PBC playback displays the menu.

Because the player's operation method and functions depend on the PBC signal recorded on the disc, PBC playback will differ according to the disc. For details, please refer to the disc's information package.


Note

- When repeat Play and Track/Time Search functions are unavailable during a menu for Video CD playback.

Title 1




Title 2



Searching For a Desired Scene (SEARCH): Part 1

Direct Search with Title Numbers

- Press **0 TITLE** during playback
(During the stop mode, proceed to step 2 without pressing the **0 TITLE** button)



- The title numbers flash on screen.

- Selecting title numbers directly with the number buttons

Press the **FUNCTION** button on the remote control unit, then press the number buttons while the **FUNCTION** indicator is lit.

- When selecting title number 3, press




- When selecting title number 10, press



- Pressing and holding the **0 TITLE** button while the **TITLE** number is flashing will advance the **TITLE** number one at a time. Choose a Title by entering the desired number and pressing the **▶/■** button.

FUNCTION indicator




FUNCTION button

Searching with the Menu


- Press **0 TITLE**

- If the stop mode is engaged, proceed to step ③.

- During playback, press



- Select a title number using the **8 R** and **2 W** buttons



- Press **5 ENTER**

- Playback of the selected title starts

Note

- ◆ With certain DVDs, the search operation may stop. In this case, the mark is displayed.
- ◆ Some discs may not include menus.

Searching for a Desired Scene (SEARCH): Part 2

Searching by Chapter/Track Number


Direct search using number buttons.

- Press the **FUNCTION** button on the remote control then press the number buttons when the **FUNCTION** indicator is lit.

Example 1: To select chapter/track number 3



Example 2: To select chapter/track number 17



Using the CHP/FRM/TIME button

① Press **CHP/FRM/TIME** button

- In this case, the **FUNCTION** indicator is lit.
- Chapter/track numbers flash on screen
- On DVDs, the menu may be displayed during the Stop Mode. Please refer to section entitled, "Chapter Number Search with the Menu".

② Select chapter/track numbers directly with the number buttons.

Example 1: To select chapter/track number 31



Example 2: To select chapter/track number 117




③ Press **▶▶|** button

- Playback of the selected chapter/track begins

Tips

- To turn off the flashing title, chapter/track/time display, press the **>10 CLEAR** button twice when the **FUNCTION** is off (indicator light is off).
- For some titles, selection can be made using a menu. If a title has a menu, press the **MENU** button while the indicator is displayed. Display the menu screen and make your selection.

FUNCTION indicator



FUNCTION button

Chapter Number Search with the Menu


Note: this operation is for DVD discs only

① Press **CHP/FRM/TIME** button

- If the StopMode is engaged, proceed to step 3.

② Press **MENU** button

- Chapter menu is displayed




③ Selection according to screen displays

- Depending upon the title, a menu may not be displayed. If no menus are available, please disregard this method.

Searching for a Desired Scene (SEARCH): Part 2

Searching by Time/Frame Number (Time Search/Frame Search)



- ① Press **CHP/FRM/TIME BACK** twice to select the frame input mode or three times to select the time input mode.




- With DVD discs authored without chapters, pressing the button once displays the frame.

- ② Select the desired time/frame number with the number buttons.

Example : To select 21 minutes 43 seconds



- Time/Frame Searches within overlapping titles are invalid. Only counts within the same title are available during searches.



- ③ Press **L NEXT**

- Playback begins at the selected start time
- For frame searching, the still frame mode is set at a certain frame however, frame count accuracy may vary depending on the method used to author the disc.

Note

- ◆ Time search is not possible on CDs.
- ◆ Time searches on DVD discs with certain Titles is possible. In this case, the mark is displayed.
- ◆ When searching a DVD using Time, playback may start at a slightly different time than that requested.
- ◆ On DVD discs, Time Search is unavailable during the stop mode.
- ◆ Searches using the above operation are not possible on a Video CD during PBC playback.

Repeat Play

Repeat Play of a Chapter/Track

During playback of the chapter or track you wish to repeat, press **FUNCTION**; when the **FUNCTION** indicator lights, press **DISP REPEAT** so that **REPEAT CHP** is displayed.

Repeat Play of a Title

During playback of a title if you wish to repeat, press **FUNCTION**; when the **FUNCTION** indicator lights, press **DISP REPEAT** so that **REPEAT TITLE** is displayed.

- With DVD discs, the title continues playing until the end then playback starts once more from the beginning of that title.
- With CDs and Video CDs, the disc is one title thus the entire disc is repeated.

Repeat Playback of All Titles (DVD)


During playback, press **FUNCTION**; with the **FUNCTION** indicator lit, press the **DISP REPEAT** so that **REPEAT ALL** is displayed.

- This operation is effective only when the menu's TITLE PLAY MODE is set to ALL (see page 3 in the Advanced Feature Operations manual).
- When playback has continued until the end of the final title, playback starts again from the beginning of Title 1.

Tips

- To cancel Repeat Play, press the **CLEAR** button when the **FUNCTION** indicator is off. The Repeat Play mode is now cancelled but playback continues normally.

FUNCTION indicator



Repeat Play of a Specified Section

Press **SUBTITLE RPT A-B** at the beginning and end of the section you want to repeat while the **FUNCTION** indicator is lit.


Return to a Specific Location

- 1 Press **SUBTITLE RPT A-B** at the desired location while the **FUNCTION** indicator is lit.
- 2 To return, press **>/<** when the **FUNCTION** indicator is off.

- Press **>10 CLEAR** to clear a specified location


Note

- ♦ With some DVD discs, there may be times when Repeat playback is not possible because of the title. In this case, the mark will appear on the screen.
- ♦ With Video CDs, Repeat Play is unavailable while a menu is displayed (PBC playback). To issue the Repeat Play command, start playback without displaying a menu, (please refer to page 16), press the **REPEAT** button.



Still Frame/Slow Play/Frame Advance

Frame by Frame Advance Playback: the picture is viewed one frame at a time



Still button

Press or

- : The picture will be advanced by one frame each time the button is pressed
- : (DVD only) Playback is reversed in small increments each time the button is pressed
- If still images appear shaky when playing back DVD stop-motion frames, set the STILL MODE to "FIELD" (refer to page 16 in the Advanced Feature Operations manual)
- Each time the is pressed, playback is reversed by 15–30 frames.

Slow Playback: view in slow-motion

Press and hold the or button during playback.

Slow playback engages
During slow playback, the slow playback speed is selected with either or

For DVD: STEP 1 (1/30) – 1/16 – 1/8 – 1/4 – 1/2
For Video CD: 1/16 – 1/8 – 1/4 – 1/2




Press and hold the button during DVD playback.

Slow motion playback in reverse (reverse slow motion speed is locked and cannot be adjusted)

Tips

- To return to normal playback, press (or the button on the player)



Stop the Picture & Set the Background Color (The disc is set to the standby mode thus keeps rotating)

Press


- Or press on the front of the player.

Note

- There is no sound when viewing still frames or when advancing one frame at a time.
- Pause may not be possible with certain discs. In this case, the mark is displayed.
- When playing DVD, pressing the button may cause the playback to advance two frames (maximum 4 frames with movies); this is normal and not a malfunction.
- Single frame advance may not be possible when playing certain movies from a DVD disc.
- The frame number displayed on the screen may be inaccurate by +/-1 frame.
- The screen will momentarily disappear during Reverse Slow Playback and Step by Step Playback (refer to page 17 of the Advanced Features Edition). To avoid this, set SQUELCH DVR SEARCH on the Advanced Feature Menu screen OFF.

Setting

Multi-Aspect Setting for Wide Screen TV Software	26
Selecting a Desired Background Color	27
Selecting Languages (Multi-Language)	28
Changing Audio Type	28
Selecting a Subtitle Language (Multi-Language Subtitles)	29
Viewing from a Desired Camera Angle (Multi-Angle)	29
Viewing Disc Information	30
Outline of GUI (Graphical User Interface) Operation	31
Changing Settings	37
How to Set Basic Audio and Subtitles	40






Multi-Aspect Setting for Wide Screen TV Software


Certain DVD discs feature image data recorded with the "squeeze" recording system for wide screen viewing. When watching this type of DVD image on a conventional television, the picture may appear vertically squeezed. If this occurs, use the Multi-Aspect function to achieve a normal look-

1. Press **MENU** during stop




The setup menu is displayed

5. Press **ENTER**




2. Select INITIAL setup with **8** and **2** buttons




The initial setup button will be displayed in blue

6. Select the desired mode (PAN & SCAN, LETTER BOX, WIDE) with the **8** and **2** buttons




3. Press **ENTER**




The initial setup screen will be displayed

7. Press **ENTER**



The picture changes to the desired type

4. Select ASPECT using **8** and **2** buttons



Pressing and holding the **2** button displays the next page's screen shown above



For DVD discs authored with multiple aspects, select the aspect that matches the TV.

Disc	Aspect selection	Wide TV (16:9)	Regular TV (4:3)
(16:9)	Wide		
	Pan & scan		
	Letter box		
(4:3)			

When the above chart's is selected, the picture with the correct height to width ratio is selected. Whether or not additional aspects are available depends on the disc. Please refer to the information written on the disc's jacket. For discs authored with a single aspect, adjust the screen using the TV controls.

Note

- Writing to the memory is not performed until the menu screen is closed. As a result, if the power cord is disconnected or a power failure occurs while the menu screen is still being set, the settings are missing from the memory.


Tips

- The width-to-height ratio of conventional TV is 4:3, while the width-to-height ratio of wide screen and Hi-Vision TV is 16:9. This width-to-height ratio is called the aspect ratio.


Selecting a Desired Background Color

Select a color for the screen and the menu displays when the unit is not playing a disc.



- Press **MENU** when the player is stopped or it is in Standby mode






(With a DVD)




- With the **8 R** **2 W** buttons, select "INITIAL" and press **5 ENTER**



- Select "B.G. COLOR" with the **8 R** **2 W** buttons, and press **5 ENTER**




- Select the desired color with the **8 R** **2 W** buttons, and adjust the color with the **4 T** **6 U** buttons



① Select a color with the buttons.

② Adjust color with the buttons.



Changes to the selected color.


- Press the **5 ENTER** button



Selecting Languages (Multi-Language)

Dolby Digital, PCM, and other audio data is recorded on DVD discs in a number of languages, languages allowing you choose which ever one is appropriate for your audience.

1. Press **AUDIO ANGLE** during playback





Tips

- Some titles provide menus for language selection. If the disc has a menu, press **MENU** button to display the menu screen then make a language selection.

Note



- The language selection option is unavailable if there is only one language authored on the disc.
- Switching the audio language may not be possible with some titles. In this case, the mark will be displayed.

2. Press **AUDIO ANGLE** to select a language



Changing Audio Type

1. Press **AUDIO ANGLE** during playback



Audio type changes each time you press the button

Note

- You cannot switch between audio type and digital output.

Tips


- With karaoke and other software, set the appropriate audio type for singing and accompaniment after referring to information on the disc jacket or accompanying material.



Selecting a Subtitle Language (Multi-Language Subtitles)


You can select a subtitle language when a DVD disc has subtitle data recorded as multiple languages.

1. Press **SUBTITLE** during playback



The currently playing subtitle number displays

2. Press **SUBTITLE** to select a subtitle language



Note

- ◆ To switch the subtitle language, more than one subtitle language stream needs to be authored on to the disc.
- ◆ Switching the subtitle language may not be possible with some titles. In this case, the mark will be displayed.

Tips






- To clear subtitles during playback, press **SUBTITLE** (after first pressing **CLEAR**). Or, clear subtitles by selecting OFF from the subtitle menu.
- Subtitles can be cleared by selecting LANG. SETUP from the INITIAL menu, and setting SUBTITLE to "OFF" (see page 38).
- For some titles, selection can be made using the menu. In this case press the **MENU** button while the indicator is lit to display the menu screen then make a selection.



Viewing from a Different Camera Angle (Multi-Angle)

Many DVD discs feature images shot from different angles so you can choose any available view.

1. Press **FUNCTION** during playback, then press **AUDIO ANGLE** while the FUNCTION indicator is lit



The camera angle changes each time you press the button

How to Check Whether a Disc is Recorded with Angles:

The jacket of discs recorded with angles are marked with the icon, . When a segment offers multi-angle views, the following symbol or icon shows on screen .

How to Hide the Angle Mark:


1. Press **MENU** during the stop mode
2. Press the **3** number button
 - The initial setup menu appears
3. Press the **1** number button
 - The OSD SETUP screen appears
4. Press the **3** number button
 - The ANGLE mark menu appears
5. Press the **2** number button
 - Menu setup is finished

Tips


- To use the Multi-Angle function, the disc must include images shot from different camera angles.
- During Multi-Angle playback, the Angle indicator on the player lights.
- For some titles, a selection can be made using the menu. In this case press the **MENU** button while the indicator is active to display the menu screen then make a selection.

Viewing Disc Information

Press **DISP REPEAT A** during playback




Press **DISP REPEAT A** when in the STOP mode




- The display changes as follows each time the button is pressed.
(disc information may be missing from some titles)

- Disc information is displayed


DVD



CD




Video CD (Playback without menu display)



Outline of GUI (Graphical User Interface) Operation


Various settings may be selected while watching menu screens and using the remote control. Menu access differs according to the disc type and playback mode (stop, pause, etc.). Refer to the following menu map for access methods.

CD, Video CD




Outline of GUI (Graphical User Interface) Operation

DVD




Press the **RETURN** button to return to to previous view/screen (before the **ENTER** was pressed).




Button Operation Within Each Menu

BUTTON NAME	BUTTON SHAPE	OPERATION
MENU button		To leave the menu screen (any new settings are discarded)
RETURN button		To move back by one menu screen (settings are memorized but the search request is ignored)
Number buttons		Selection and conclusion (in the set up menu, some items operate only for selecting functions)
Direction buttons		Selection
ENTER button		Setting and implementation (playback mode is engaged after title or chapter change)
PREVIOUS button		To go to the previous page
NEXT button		To go to the next page
Direct buttons		To go to menus (settings selected before moving to a new menu are ignored)
FUNCTION button		To toggle between button options



Example of Screen Displays and Operation

Ex. 1: Display contents and button functions within the Menu screen



Class is indicated by tag indicators

When the ◀ and ▶ marks are displayed, settings may be changed with the ◀ ▶ buttons

Memorizes any changes that have been made to the above settings

Item numbers

Selecting an item number by pressing the **number buttons** or using the ◀ ▶ buttons and then pressing the **ENTER button** displays the menu screen for that item number. However, selecting item "5 ENTER" memorizes the changed settings and quits the mode.




Ex. 2: Display Contents and Button Functions Within the Setup Menu

Current Setup Condition

Item numbers are selected with the ◀ ▶ buttons but settings are changed with the ◀ ▶ buttons.

Current Setup Condition

When selecting a setting using number buttons or the ◀ ▶ buttons, pressing the ENTER button displays the selected screen.




Selecting this memorizes changed settings and quits the mode

Selection Item N numbers

Selections are made with the number buttons. Selecting "OSD SET.", "SAVER", "B.G.COLOR", "PARENTAL", "SOFT MENU", "LANG SET" or "ASPECT" displays the appropriate screen for that selection. Also, changing the settings with the ◀ ▶ buttons then pressing the **ENTER button** memorizes the settings and quits the mode.

About the Main Menu

Use the Main menu to select the Title Menu, Menu and Setup screens.



Title Menu screen:

To select and playback Titles (Title search)

Menu screen:

To select chapters (songs), subtitles, audio tracks and angles from within a title


Initial Setup screen:

The various player functions player can be set using the screen displays

Output Setup screen:


To output audio from the digital output terminal

About the Title Menu



Titles can be selected and played back. This screen is identical to the display discussed in "Searching with the Menu" on page 20.

Menu Screen Contents



To go to the Chapter screen

Chapter screen:

One chapter (song) within a title can be selected and played back

To go to the Audio screen

Audio screen:

On discs with more than one audio track, Audio contents can be selected

To go to the Subtitle screen

Subtitle screen:

On discs that include subtitle data, a Subtitle track can be selected

To go to the Angle screen


Angle screen:

If a disc includes scenes filmed from different views, select from among the available angles.

Completes the setting of changes to the above items.


Changing Settings

About the Initial Setup Screen



Use this screen when changing various settings including display, position, screen saver, etc.
(refer to the following pages for details)

About the Output Setup Screen



Use this screen when selecting the audio to be output through the output terminal.
The setting must comply with the amplifier being used.
(refer to the following pages for details)

Item Settings

Class		Item	Details	Settings		
				Initial settings (factory settings at the time of shipment)		
INITIAL	OSD. SET	DISPLAY	Selecting ON or OFF hides or reveals the Operation displays (play, stop etc.)	ON Operation displays appear	OFF Operation displays do not appear	
		POSITION	When watching conventional software on a wide screen TV, the operation display is on the top right of the screen thus may not be visible. Changing the position of the display reveals the operation indicators clearly on wide TV screens.	NORMAL When using a conventional TV (4:3)	WIDE When using a wide screen TV (not for menu displays)	
		ANGLE MARK	When a picture is available for viewing at different angles, then  is displayed This setting identifies any sequences with multiple angles	ON  is displayed	OFF Not displayed	
		SAVER (Screen Saver)	When a paused image is displayed for a long period of time, the image may be "burned" onto the screen. The DVD-V7200 includes a screen saver function in order to prevent screen burn whenever an image such as a menu screen etc., is continuously displayed for an extended period (more than 5 minutes). It is best to this set to BLACK or B.G. COLOR. BLACK: Screen turns to black when screen saver operates B.G.COLOR: During operation of the screen saver, the screen turns to the selected B.G.COLOR OFF: Screen saver will not operate	OFF Screen Saver is deactivated	B.G. COLOR Screen Saver is active	BLACK
		B.G. COLOR (Background color)	To select a Menu screen or Stop mode screen color	R : 0% G : 50% B : 50%	Adjustable Adjust each color within 20 levels	
		PARENTAL	This controls or blocks undesirable material Discs authored with Parental Lock enabled provide a method to skip material that may be inappropriate for all audiences. For details, refer to the instructions that come with a disc. Input a 4-digit number selected by you in order to view a level (user restriction level). The code is locked in until you change it. Be sure to choose a number that is easily remembered. If the number is forgotten or lost, return to the default setting and enter a new 4-digit code.	LEVEL 8	Level 1-8 Variable	
		SOFT MENU	This lets you select the desired menu language when playing discs authored with different languages.	ENGLISH	Select the desired menu language	
	LANG. SETUP	AUDIO	Select a language if the disc is authored with various audio languages. When the audio language is changed during playback, the language remains as the selected audio for the next disc to be played.	ENGLISH	Select from 136 different languages (selection method is explained on page 40)	
		SUBTITLE	The subtitle language is selected from the subtitles on a disc. When the subtitle language is changed during playback, the language remains as the selected subtitle for the next disc to be played.	ENGLISH	Select from 136 different languages. Selection method is explained on page 40.	

Item Settings


Class		Item	Details	Settings		
				Initial settings (factory settings at the time of shipment)		
INITIAL	LANG. SET UP	AUTO	ON AUDIO and SUBTITLE can be set in advance. In the case of foreign movies, the original audio language and English subtitles are automatically selected In the case of English language movies, the original audio language (English) is selected, and subtitles are not displayed On some discs, this function may not operate as described above. If AUDIO and SUBTITLE differ or DISPLAY and ASS.SUBTIT of the SUBTITLE are OFF, it is the same as turning it OFF. But, changing settings during playback using "Selecting Languages" (page 28) and "Selecting Subtitle Language" (page 29) is possible. OFF Regular subtitle and audio settings are selected	ON	OFF	
		SUBT.OFF (Subtitle off)	A subtitle can be set while the subtitle is set to OFF. SEL SUBTL: The selected subtitle language will be selected. WITH AUDIO: The selected audio language will be selected.	SEL SUBTL	WITH AUDIO	
		ASPECT	When viewing software recorded in the wide mode, the image's height to width ratio can be switched to match the TV being used.	WIDE	PAN & SCAN	LETTER BOX
OUTPUT		DIG. OUTPUT (Digital output)	This player lets you change the audio output via PCM/  of the coaxial digital output jack. DVD conforms to both Dolby Digital (three-dimensional sound for movies etc.) and Linear PCM (digital sound with higher fidelity than CD) audio standards.	PCM /DOLBY DIGITAL Automatically selects Linear PCM or Dolby Digital depending on the audio signal (when an amp that includes a Dolby digital [C-3] decoder is used)	PCM Provides Linear PCM sound with both Dolby Digital and Linear PCM sources (when a regular amp or Dolby Pro logic amp is used)	
		DOWN SAMP (Down sample)	96kHz: PCM audio discs with a 96kHz sampling frequency can be played back at the 96kHz high quality sound setting while 48kHz discs will be played back at 48kHz 48kHz: Discs with a 96kHz sampling frequency can be played back at a compressed 48kHz with this setting and 48kHz discs will be played back at 48kHz - When the audio sampling frequency recorded on the disc is set as desired, output toggles between analog and digital output - When the 96kHz setting is selected for a disc with copy protection, the signal is blocked from the digital output terminal	96kHz	48kHz	

Returning changed settings to the original settings (initialization)...

Verify that the power is turned OFF. With the power OFF, press both the  button and the  button.



How to Set Basic Audio and Subtitles

AUDIO




Changes according to the signals from the or on the remote control

SUBTITLE



- When the auto setting is ON (page 39), the English audio and subtitles may differ from the language set for the basic audio and basic subtitles, because auto setting is given priority.

Refers to the input codes (high or low order) on the language code list. Use the remote control to select the number corresponding to the required language
Note:
(For selection of numbers greater than 10, use the button).



After selecting this display with the remote control's or button, Display ON or Display OFF can be selected with the remote control's or button

On some discs, subtitles that explain the scene condition have been recorded to assist the hearing impaired. To display these subtitles set the ASS.SUBTIT to ON.

Language code list

Language	Language-code	Input-code (high-order)	Input-code (low-order)
Japanese	ja	10	01
English	en	05	14
French	fr	06	18
German	de	04	05
Italian	it	09	20
Spanish	es	05	19
Dutch	nl	14	12
Russian	ru	18	21
Chinese	zh	26	08
Korean	ko	11	15
Greek	el	05	12
Afar	aa	01	01
Abkhazian	ab	01	02
Afrikaans	af	01	06
Amharic	am	01	13
Arabic	ar	01	18
Assamese	as	01	19
Aymara	ay	01	25
Azerbaijani	az	01	26
Bashkir	ba	02	01
Belorussian	be	02	05
Bulgarian	bg	02	07
Bihari	bh	02	08
Bislama	bi	02	09
Bengali, Bangla	bn	02	14
Tibetan	bo	02	15

Language	Language-code	Input-code (high-order)	Input-code (low-order)
Breton	br	02	18
Catalan	ca	03	01
Corsican	co	03	15
Czech	cs	03	19
Welsh	cy	03	25
Danish	da	04	01
Bhutani	dz	04	26
Esperanto	eo	05	15
Estonian	et	05	20
Basque	eu	05	21
Persian	fa	06	01
Finnish	fi	06	09
Fiji	fj	06	10
Faroese	fo	06	15
Frisian	fy	06	25
Irish	ga	07	01
Scottish Gaelic	gd	07	04
Galician	gl	07	12
Guarani	gn	07	14
Gujarati	gu	07	21
Hausa	ha	08	01
Hindi	hi	08	09
Croatian	hr	08	18
Hungarian	hu	08	21
Armenian	hy	08	25
Interlingua	ia	09	01

Language	Language-code	Input-code (high-order)	Input-code (low-order)
Interlingue	ie	09	05
Inupiak	ik	09	11
Indonesian	in	09	14
Icelandic	is	09	19
Hebrew	iw	09	23
Yiddish	ji	10	09
Javanese	jw	10	23
Georgian	ka	11	01
Kazakh	kk	11	11
Greenlandic	kl	11	12
Cambodian	km	11	13
Kannada	kn	11	14
Kashmiri	ks	11	19
Kurdish	ku	11	21
Kirghiz	ky	11	25
Latin	la	12	01
Lingala	ln	12	14
Laotian	lo	12	05
Lithuanian	lt	12	20
Latvian, Lettish	lv	12	22
Malagasy	mg	13	07
Maori	mi	13	09
Macedonian	mk	13	11
Malayalam	ml	13	12
Mongolian	mn	13	14
Moldavian	mo	13	15
Marathi	mr	13	18
Malay	ms	13	19
Maltese	mt	13	20
Burmese	my	13	25
Nauru	na	14	01
Nepali	ne	14	05
Norwegian	no	14	15
Occitan	oc	15	03
(Afan) Oromo	om	15	13
Oriya	or	15	18
Panjabi	pa	16	01
Polish	pl	16	12
Pashto, Pushto	ps	16	19
Portuguese	pt	16	20
Quechua	qu	17	21
Rhaeto-Romance	rm	18	13
Kirundi	rn	18	14

Language	Language-code	Input-code (high-order)	Input-code (low-order)
Rumanian	ro	18	15
Kinyarwanda	rw	18	23
Sanskrit	sa	19	01
Sindhi	sd	19	04
Sango	sg	19	07
Serbo-Croatian	sh	19	08
Singhalese	si	19	09
Slovak	sk	19	11
Slovenian	sl	19	12
Samoa	sm	19	13
Shona	sn	19	14
Somali	so	19	15
Albanian	sq	19	17
Serbian	sr	19	18
Siswati	ss	19	19
Sesotho	st	19	20
Sundanese	su	19	21
Swedish	sv	19	22
Swahili	sw	19	23
Tamil	ta	20	01
Telugu	te	20	05
Tajik	tg	20	07
Thai	th	20	08
Tigrinya	ti	20	09
Turkmen	tk	20	11
Tagalog	tl	20	12
Setswana	tn	20	14
Tongan	to	20	15
Turkish	tr	20	18
Tsonga	ts	20	19
Tatar	tt	20	20
Twi	tw	20	23
Ukrainian	uk	21	11
Urdu	ur	21	18
Uzbek	uz	21	26
Vietnamese	vi	22	09
Volapük	vo	22	15
Wolof	wo	23	15
Xhosa	xh	24	08
Yoruba	yo	25	15
Zulu	zu	26	21

Set-Up

Connecting the Player

Connection example 1. ● Television (monitor TV) ● Control Computer ● Sync Generator	45
Connection example 2. AV receiver with digital input for Dolby Digital (AC-3)	47
Connection example 3. AV amp	48
Connection example 4. Digital recording components	48
Using a Laser Bar-code Scanner (Sold Separately)	50

Other Information

For Proper and Long Use	51
Troubleshooting	52
Terms	53
Specifications	55

Connecting the Player

Precautions when Connecting the Player


This player's Analog copy protect technology is copy guarded. If the player is connected to a TV via a VCR, or try to record and playback the contents of a disc through a VCR, the picture may not appear normal.

Video out




- Match the colors on the connect plugs and the terminals colors: white, red, yellow

Audio out




S-Video out




- Connect the S-VIDEO terminal on the TV to the S-VIDEO OUT terminal of this player

Interface Connector (RS-232C)



- Align the plug with the connector and insert then tighten the lock screws

External Sync Input (BNC)




- Align the plug properly with the tab on the connector. Press the plug in carefully then rotate to the right to lock

Note

☆ Cables can be found at local audio/video dealers


Connection Example 1

- **Television (monitor TV),**
- **Control Computer**
- **Sync Generator**




These instructions indicate the connections made when connecting this component directly to a television (monitor TV) for DVD disc playback.

- Please refer to the Advanced Operating Instructions manual for additional information concerning TV (monitor TV) connections



When synchronizing two or more players

- Use a single sync generator to synchronize two or more players
- Intermediate players (players connected between two components) should have the VIDEO TERMINATOR switched OFF




Note

- The external synchronizing function only operates with DVD discs
- Locking of the sub carrier element to the black burst signal does not occur
- During the approximately 5 seconds needed for locking to the external synchronizing signal, there is some video disturbance at the video output jacks
- Input the external synchronizing signal before playing a DVD disc; synchronization fails if commands are sent after playback begins

☆ Cables can be found at local audio/video dealers

Connection Example 2


AV receiver with digital input for Dolby Digital (AC-3)



To connect the DVD-V7200 to an amp with Dolby Digital (AC-3) inputs

* Make this connection when using this unit with Pioneer's VSX-07TX, VSX-09TX AV receiver.

- Connect the player's digital output PCM/DIGITAL jack to the Dolby Digital (AC-3) input jack of a compatible amplifier
- Select whether to use the coaxial digital output according to the amplifier's input jack



Finally, connect to a home wall outlet


- Some discs may not allow digital output when this player's output down sampling is set for 96kHz (see page 39)

Note

☆ Cables can be found at local audio/video dealers


Connection Example 3

AV amp



By connecting to a regular AV amp or stereo amp, you can enjoy playback with improved sound quality.

Connect the player's audio output jacks to an amp's CD, LD, AUX or other audio input jacks. (Do not connect to PHONO jacks)
Connect the player's video output jack to the amp's video input jack




When connecting to a component bearing the Pioneer **SR** mark:

If you use a commercially available cord with a mini plug (no resistance) to connect this player's EXT.CONT jack to the control output jack of another component bearing the **SR** mark, the player is controlled as if it were a component in a system (system control).

- A player under system control, ignores commands sent through the remote control.
- Connect the amplifier using an audio cord, even if using only digital components when the system controls the unit
- Surround sound can be enjoyed with amplifiers that have a built-in Dolby Pro Logic decoder
- For further information, refer to the other device's operation manual

Connection Example 4


Digital recording components



Digital recording components such as an MD, CD-R or DAT may be connected

Make digital output (Coaxial) connection

- Connect the DVD player's PCM/DIG output connector to the digital input connector on the device used for digital recording



Note

When recording a Dolby digital compatible DVD, set "Digital output" to the PCM setting as explained on page 39. When the disc is recorded in Dolby Digital (AC-3), noise is audible if the setting is left at PCM/DOLBY DIGITAL

Cables can be found at local audio/video dealers


About the Interface Connector

RS-232C interface

The DVD-V7200 is equipped with one serial interface connector conforming to RS-232C standards. When controlling the player through the computer's RS-232C interface, use RS-232C connector on the back of player.

① Connector

15-pin D-SUB connector, female



② Signal line

This line supports the signals shown on the diagram.

RS-232C signal line

Pin no.	Pin name	Input/Output	Function
1	GND	–	Ground
2	TxD	Output	Transmission output
3	RxD	Input	Reception input
4	DTR	Output	Transmission enable
5	POWER	Input	External power control
6	SW1	Input	*1
7	SW2	Input	*1
8	SW3	Input	*1
9	SW4	Input	*1
10	SW5	Input	*1
11	SW6	Input	*1
12	SW7	Input	*1
13	SW8	Input	*1
14	DLTST	Input	Service connector (do not use this terminal)
15	V+8V	Output	Service connector (do not use this terminal)


* 1 Connect an external switch to this terminal to control the player

- Consult the User's Manual for detailed information regarding this terminal and RS-232C control commands

③ Connections to a computer


Connect the computer to the DVD-V7200 as shown below. (control is possible when the three lines are connected)

RS-232C interface and computer connections



A player accepts commands at any time. It is unnecessary to connect control lines other than TxD and RxD when joining to a computer with a standard RS-232C port. Some computers fail unless the CTS input is hard-wired. In this case, the DTR output is used. If the DTR is active, a "+" electric potential is output.

RS-232C ports are shown below: (cable sold separately)



Using a LaserBarcode Scanner (Sold Separately)

■ LaserBarcode Scanner


To transmit signals using the optional LaserBarcode Scanner (UC-V108BC) in the wired mode, connect the scanner to the player's front-panel EXT.CONT jack.

To transmit barcodes in the wireless mode, use the remote control (refer to the LaserBarcode Scanner Operating Instructions for full instructions).


Note

- ◆ While using the LaserBarcode Scanner, sending commands to the player (through the remote control, buttons on the player, or serial commands from a computer) may cause unit lock-ups and malfunctions. To avoid accidental commands being sent to the player, the remote control is disabled while the LaserBarcode Scanner is in the wired mode. Thus, it is best to set up the system in the wired mode when using a LaserBarcode Scanner.
- ◆ When the player is operated via barcodes, the on-screen displays are hidden.
- ◆ When a CD, Video CD or CDV disc is loaded, barcode commands issued for LD or DVD are ignored.
- ◆ When a DVD is loaded, commands issued for CDs are ignored.

Wireless Mode:



Wired Mode:



For Proper and Long Use

■ DO NOT MOVE THE UNIT DURING PLAYBACK

During playback, the disc rotates at high speed. Do NOT lift or move the unit during playback. Doing so may damage the disc.

■ HOW TO MOVE THE PLAYER

When preparing this component to be moved, first remove any disc loaded and press the STOP/OPEN/CLOSE ■/▲ button to close the disc table. Next, turn the power OFF; after the STANDBY indicator changes to orange, disconnect the power plug from the electrical outlet.

■ INSTALLATION

- Select a stable place to the side of other equipment
- Do NOT install the unit on top of a TV or color monitor. Install the unit away from equipment that may be affected by magnetism, such as a cassette deck.

■ AVOID INSTALLING IN PLACES WITH THE FOLLOWING FEATURES:

- Exposed to direct sunlight
- Exposed to humidity or where ventilation is poor
- Extremely hot or cold
- Exposed to vibration
- Exposed to dust
- Exposed to oily smoke, steam or heat

■ DO NOT PLACE AN OBJECTS ON TOP

Do NOT place any object on the unit

■ DO NOT BLOCK VENTS

Do NOT place the player on a long or loose-fibered carpet and avoid covering with a cloth, etc. This prevents over-heating which could cause damage to the unit.

■ AVOID HEAT


Do NOT place the unit on top of equipment which generates heat such as an amplifier or other audio devices. When installing the unit in a rack, place it on the lowest shelf possible (but not where it is exposed to dust) and separate from the amplifier to avoid any possible heat damage.

■ CAUTION: IF PLACING THE UNIT IN A STEREO RACK WITH GLASS DOORS

Be sure there is ample space between the unit and the glass doors when opening the disc table. If the disc table opens against strong resistance, such as a closed glass door, the player may be damaged.

■ SWITCH THE POWER OFF WHENEVER THE PLAYER IS NOT IN USE

Depending on the strength of the TV broadcast signal, having the TV set on while the power of the unit is ON may produce stripes on the TV screen. This is normal behavior and not a malfunction of either unit. In this case, switch the player OFF.



POWER-CORD CAUTION

Handle the power cord by the plug. Do not pull out the plug by tugging the cord and never touch the power cord when your hands are wet as this could cause a short circuit or electric shock. Do not place the unit, a piece of furniture, etc., on the power cord, or pinch the cord. Never make a knot in the cord or tie it with other cords. Route power cords so that they are unlikely to be stepped on or pinched. A damaged cord can cause a fire or give you an electrical shock.

Check the power cord periodically. If it is damaged, ask the nearest PIONEER authorized service center or your dealer for a replacement.

Troubleshooting

Incorrect operations are often mistaken for trouble and malfunctions. If you think that there is something wrong with this component, check the items below. Sometimes the trouble may lie in another component. Inspect the other components and electrical appliances being used. If the trouble cannot be rectified even after exercising the checks listed below, ask your nearest PIONEER authorized service center or your dealer to carry out any repair work.

	Symptom	Possible causes	Reference page
Operation	1. The disc comes back out even when the disc table is closed	● The disc is dirty or warped ● The disc is not placed properly on the disc table ● Region number on disc and player do not match	p.11 p.10 p.54
	2. Playback is impossible	● Condensation has formed inside the player ● This player plays the NTSC format only (not PAL or SECAM format)	p.9
	3. Picture disturbance during playback	● This player is compatible with MacroVision System copy guard. Some discs include a copy prevention signal thus when this type of disc is played back, stripes etc., may appear on some sections of the picture (depending on TV model - this is not a malfunction)	p.44
	4. When recorded to a VCR there is disturbance in the playback picture	● This player is compatible with analog copy protect technology copy guard. Some discs include a copy prevention signal thus the copy guard system prevents proper playback	p.44
	5.  mark appears on screen	● The selected function does not operate for that disc	
	6. Picture playback stops and the operation button can not be used	● First stop the disc (press the  button), then start playback again	
Remote control	7. Remote control operation is not possible	● The front-panel EXT CONT jack is connected ● The remote control is too far from the player, or the angle with the remote sensor is too wide. ● The batteries are low ● A number is input without pressing the FUNCTION button first	p.14 p.8
	8. Improper operation of TV set occurs	● Some TVs that have wireless remote control functions may not operate properly with this remote control	
Audio	9. Audio is missing or is distorted	● The digital output setting is set to 96KHz (digital output is prohibited for some discs) ● The connection plugs are not inserted fully into the terminals or are not connected ● The connection plug or terminal is dirty ● Audio cable is connected incorrectly ● Connection is made to the stereo amplifier's PHONO input terminal ● The pause mode is engaged ● Stereo amplifier is connected incorrectly (Check input - CD, AUX etc. - selector)	p.40 p.44~48
	10. Noticeable difference in DVD and CD volumes	● There may be a difference in volume between a CD and a DVD disc because of the original recording methods	

Caution: Abnormal functioning of this unit may be caused by static electricity or other external interference. To restore normal operation, unplug the AC power cord then plug it in again.

Terms

Dolby Digital (AC-3)*

The maximum 5.1 channels of audio used in the surround system (Surround Digital) for movie theaters is digital data compressed by AC-3.



For DVD discs, the digital output PCM/  jack is connected to the amplifier or processor's digital input AC-3/PCM jack.

PCM

PCM stands for Pulse Code Modulation which is a digital audio system. The digital audio of CD or DVD discs is PCM.

Title Number

Title numbers refer to titles of movies etc. As DVD discs have a large capacity, more than a single movies can be recorded on a disc. For example, if 3 movies are recorded on a disc, they are divided into TITLE 1, TITLE 2 and TITLE 3. Select the title number to choose which movie plays back.

Chapter number

Chapter numbers are the numbers assigned to sections on a title of the disc similar to chapters in a book. If the disc includes these numbers, you can locate the section you want very quickly using chapter search and other functions.

Time number

The time number is the playback lapse time of a title in the disc from its beginning. The scene you want to locate can be searched for with the time number using the time number and other function.

TOC

TOC (Table Of Contents) information is data other than audio signal data recorded at the beginning of a disc. As the name implies, it is like a list of contents in a book. The TOC contains data such as the number and length of songs.

Video CDs

These discs provide MD quality sound and VHS quality video images. MPEG1, the digital signal compression system, supports up to 74 minutes of continuous digital audio and video on a single disc. There are also Video CDs with PBC (Playback Control) for playback using menus and to view still images.

Playback Control (PBC)

This refers to signals recorded on a Video CD (Version 2.0) enabling playback control.

Use menus recorded on discs with PBC for easy, interactive scene searches and playback options.

You can also enjoy viewing high-resolution/standard resolution still images.

High-Resolution Images

If high-resolution still images are recorded on a Video CD, you can enjoy viewing them with four times the resolution of moving images.

Multi-Angle

When you watch regular TV programs you are watching the image filmed through a TV camera. The angle is the image seen from the view point of a TV camera. In a TV studio, the scene is filmed by many cameras positioned throughout the studio. The program director chooses the view or angle to be broadcast. If some or all of the filmed pictures were transmitted to your TV, you would be able to select from any angle you wished to see. Some DVDs are recorded with multiple angles. These discs are called multi-angle discs.

Aspect

Aspect ratio refers to the length to height ratio of TV screens. The ratio of a normal TV is 4:3, while the ratio of a Hi-vision TV or wide TV is 16:9. This allows you to enjoy a picture with a wider perspective.

Parental level

Parental level control allows restrictions to be set on a scene by scene basis. This feature was originally designed for parents to prevent their children from viewing selected movies.

Subtitle

Subtitles are language titles superimposed on movies. Up to 32 different subtitle languages can be added to a DVD disc. Each subtitle may be set to a different language or other video elements.

* Manufactured under license from Dolby Laboratories, "Dolby", "AC-3" and the double-D symbol are trademarks of Dolby Laboratories. Confidential Unpublished Works, © 1992-1997 Dolby Laboratories, Inc. All right reserved.

Terms

Regional Restriction Codes (Region Number)

Restriction codes are built-in to DVD players and discs for each region (refer to a Region Code Chart). If the player's region code is different than one of the region codes on a DVD disc, playback fails.

*The Region Code is imprinted on the back of the DVD-V7200

Playable		Unplayable	
Player	Disc	Player	Disc
	 	 	 

Dynamic Range

Dynamic range refers to the difference between the maximum conversion level for transmission/conversion (of distortion free signals) and noise and/or the minimum rateing of the other equipment.

* Measurements are made in decibel units (dB).

Specifications

General

System DVD system and Compact Disc digital audio system
 Laser Semiconductor laser: wavelength 650 nm
 Power requirements: AC 120 V, 60 Hz
 Power consumption 23 W
 Weight 4.7 kg (10 lb 6 oz)
 Dimensions 210 (W) x 408 (D) x 119 (H) mm
 (8 ¹/₄ x 10 ¹/₁₆ x 4 ¹/₁₆ in.)
 (Not including protruding cables, etc.)
 Operating temperature +5°C to +35°C (+36°F to +96°F)
 Operating humidity No more than 85% (no condensation)

S-Video Output

Y (luminance) - Output level 1 Vp-p (75Ω)
 C (color) - Output level 286 mVp-p (75Ω)
 Jacks S-VIDEO jack

Video Output

Output level 1 Vp-p (75Ω when loaded, synchronous negative)
 Jacks RCA

External synchronizing input

Input signal level Black burst
 0.3 Vp-p (with 75 Ω load) BNC x 2 (loop through)

Audio Output

Output level
 During audio output 200 mVrms (1 kHz, -20 dB)
 Number of channels 2
 Jacks RCA

Digital audio characteristics

Frequency response	4 Hz to 22 kHz (DVD fs: 48 kHz) 4 Hz to 20 kHz (CD)
S/N ratio	115 dB (EIAJ) (typical)
Dynamic range	97 dB (EIAJ) (typical)
Total harmonic distortion	0.003 %
Wow and flutter	±0.001% W. PEAK or lower (EIAJ)

Other Terminals

Coaxial digital output (PCM/ ) RCA jack
 Communication interface D-SUB, 15-pin

Accessories

Remote control unit	1
AA (R6P) dry cell batteries	2
Audio cord	1
Video cord	1
Laser bar-code Sheet	1
RF adaptor set clamp	1
Screw	1
Operating Instructions (Basic Operations)	1
Operating Instructions (Advanced Feature Operations)	1
Warranty card	1

NOTES:

- All values listed in these specifications are standard values.
- The specifications and design of this product are subject to change without notice, due to improvement.



Dear Customer:

Selecting fine audio equipment such as the unit you've just purchased is only the start of your musical enjoyment. Now it's time to consider how you can maximize the fun and excitement your equipment offers. This manufacturer and the Electronic Industries Association's Consumer Electronics Group want you to get the most out of your equipment by playing it at a safe level. One that lets the sound come through loud and clear without annoying blaring or distortion-and, most importantly, without affecting your sensitive hearing.

Sound can be deceiving. Over time your hearing "comfort level" adapts to higher volumes of sound. So what sounds "normal" can actually be loud and harmful to your hearing. Guard against this by setting your equipment at a safe level BEFORE your hearing adapts.

To establish a safe level:

- Start your volume control at a low setting
- Slowly increase the sound until you can hear it comfortably, clearly and without distortion

Once you have established a comfortable sound level:

- Set the dial and leave it there

Taking a minute to do this now will help to prevent hearing damage or loss in the future. After all, we want you listening for a lifetime.

We Want You Listening For A Lifetime

Used wisely, your new sound equipment will provide a lifetime of fun and enjoyment. Since hearing damage from loud noise is often undetectable until it is too late, this manufacturer and the Electronic Industries Association's Consumer Electronics Group recommend you avoid prolonged exposure to excessive noise. This list of sound levels is included for your protection.

Decibel

Level	Example
30	Quiet library, soft whispers
40	Living room, refrigerator, bedroom away from traffic
50	Light traffic, normal conversation, quiet office
60	Air conditioner at 20 feet, sewing machine
70	Vacuum cleaner, hair dryer, noisy restaurant
80	Average city traffic, garbage disposals, alarm clock at two feet.

THE FOLLOWING NOISES CAN BE DANGEROUS UNDER CONSTANT EXPOSURE

90	Subway, motorcycle, truck traffic, lawn mower
100	Garbage truck, chain saw, pneumatic drill
120	Rock band concert in front of speakers, thunderclap
140	Gunshot blast, jet plane
180	Rocket launching pad

Information courtesy of the Deafness Research Foundation.



Should this product require service in the U.S.A. and you wish to locate the nearest Pioneer Authorized Independent Service Company, or if you wish to purchase replacement parts, operating instructions, service manuals, or accessories, please call the number shown below.

1 – 8 0 0 – 872 – 4159

Please do not ship your product to Pioneer without first calling the Customer Service Department at the number listed above.

PIONEER ELECTRONICS SERVICE, INC.
CUSTOMER SUPPORT DIVISION
P.O. BOX 1760, LONG BEACH,
CA 90801-1760, U.S.A.

For warranty information please see the Limited Warranty sheet included with your product.

Should this product require service in Canada, please contact a Pioneer authorized dealer in Canada to locate the nearest Pioneer Authorized Service Company.

Alternatively, please contact or ship your defective product freight prepaid to one of the following Factory Service locations closest to you:

Pioneer Electronics of Canada, Inc.

Factory Service East
300 Allstate Parkway
Markham, ON L3R 0P2
(905) 479-4411

Factory Service West
13911 Bridgeport Road
Richmond, BC V6V 1J6
(604) 278-1014

For warranty information please see the Limited Warranty sheet included with your product.

Si ce produit doit être réparé au Canada, veuillez vous adresser à un distributeur autorisé Pioneer au Canada pour obtenir le nom de la société de service autorisée Pioneer la plus près de chez vous. Ou encore, veuillez communiquer avec le centre de service en usine Pioneer le plus près de chez vous ou faire parvenir l'article défectueux, port payé, à ce centre.

Pioneer électroniques du Canada, Inc.

Service en usine - Est
300 Allstate Parkway
Markham (Ontario) L3R 0P2
(905) 479-4411

Service en usine - Ouest
13911 Bridgeport Road
Richmond (C.-B.) V6V 1J6
(604) 278-1014

Pour obtenir des renseignements sur la garantie, veuillez vous reporter au feuillet sur la Garantie Limitée qui accompagne le produit.

Published by Pioneer Electronic Corporation.
Copyright © 1998 Pioneer Electronic Corporation.
All rights reserved.

PIONEER ELECTRONIC CORPORATION

4-1, Meguro 1-Chome, Meguro-ku, Tokyo 153-8654, Japan

PIONEER ELECTRONICS [USA] INC. P.O. BOX 1540, Long Beach, California 90801-1540

PIONEER ELECTRONICS OF CANADA, INC. 300 Allstate Parkway, Markham, Ontario L3R 0P2, Canada

PIONEER ELECTRONIC [EUROPE] N.V. Haven 1087, Keetberglaan 1, 9120 Melsele, Belgium TEL: 03/570.05.11

PIONEER ELECTRONICS AUSTRALIA PTY. LTD. 178-184 Boundary Road, Braeside, Victoria 3195, Australia, TEL: [03] 9586-6300

PIONEER ELECTRONICS DE MEXICO S.A. DE C.V. San Lorenzo Num 1009 3er piso Desp. 302 Col. Del Valle, Mexico D.F. C.P. 03100 TEL: 5-688-52-90



DVD PLAYER

DVD-V7200

Operating Instructions (Advanced Feature Operations)

NTSC

Thank you for buying this Pioneer product.
Please read through these operating instructions so you will know how to operate your model properly. After you have finished reading the instructions, put them away in a safe place for future reference.




INTRODUCTION

The Basic Operating Instructions denotes handling methods while this Advanced manual explains original features of the DVD-V7200 player.


● Connection of mouse and keyboard

How to connect the mouse and keyboard to this unit is explained in this section



● Player Control Using the Mouse

Control method using the mouse is explained in this section





● Advanced Feature Menu

Besides the player menu (explained in the Basic Operation edition) this unit also has an Advanced Feature menu. This section explains details of weekly timer and power on start setup etc., using this menu



● Video Blackboard Function

Using the mouse and keyboard, pictures, lines and characters (alphabet, numbers, symbols) can be drawn during video playback or displayed alone.


Free lines can be drawn on the picture during playback, and pre-drawn drawings or characters can be superimposed on the image and displayed at a specified position during playback.



Curved lines can be drawn with the mouse



Pre-drawn drawings or characters can be automatically superimposed on the playback picture



Uses


- A pointer
- For picture subtitle
- For picture explanation
- For picture masking

● Barcode/command stack function

Various barcodes or commands used to control the DVD-V7200 can be stored in this player's memory in advance.

Memorized content can be recalled for successive or step by step execution.

With this function, program playback is possible using the player alone without the need for a computer, controller or advance registration of barcodes.



● Others

External synchronizing function


Playback time/Power supply time display

CONTENTS

Introduction	2		
Connection of mouse and keyboard	5		
Player control using a mouse	6		
Player control icon	6		
Advanced feature menu			
Advanced feature menu setting	8		
Advanced feature menu setup	9		
Displaying the menu screen	9		
Clearing the menu screen	9		
Weekly Timer operation	10		
Setting/correcting the current time.	10		
Setting the weekly timer	11		
Clearing the set time	12		
Playing the specified title and chapter	12		
Setup for recalling displaying the Barcode/command stack groups from memory	13		
Setting the timer function to not operate with the weekly timer setting left as is	13		
Power on start function	14		
Power on start function	14		
Tuning off the power on start function	15		
Advanced feature menu detailed information			
Title play mode setup	16		
Repeat mode setup	16		
Baud rate setup	16		
Tray lock setup	16		
Black board lock setup	16		
Still mode setup	16		
D.R.COMP setup	16		
Mark frame squelch setup	17		
Squelch dur search setup	17		
Sync out (during sq) setup	17		
Stack mode osd setup	17		
DVD VIDEO BLACKBOARD			
Character input/picture drawing	18		
Operation using the mouse or keyboard	18		
Activating the blackboard function	18		
Inputting characters	18		
Using the drawing tools	19		
Drawing a picture	19		
Saving			
Saving characters or pictures	20		
Details on the blackboard	20		
To change the display mode	21		
Pencil tool/Freehand drawing	21		
Grouping video blackboards			
Grouping blackboards	22		
Executing an entire group to execute a group	22		
To execute steps in a group	22		
Recalling/executing previously input blackboards while observing their list	23		
BARCODE/COMMAND STACK FUNCTION			
Introduction	24		
Basic usage	24		
Advanced usage	24		
Barcode/Command Stack Setting			
Displaying the Barcode/Command Stack screen	25		
Direct setting using a barcode reader	26		
Setting using the remote control unit	26		
Setting the Subtitle, Audio and Angle	29		
To use only the chapter search or frame search	29		
To change a value during input	29		
To cancel input in the middle	29		
Setup of LASERBARCODE compatible discs			
Video, audio setup	30		
Saving a Barcode/Command Stack	31		
To delete a previously input Barcode/Command Stack	32		
Correcting a previously input Barcode/Command Stack ..	33		
Adding a step in a previously input Barcode/Command Stack	34		
Grouping some Barcode/Command Stacks	35		
Switching the barcode command stack group	36		
Deleting a group	36		
Dividing a previously input group	38		
Joining two Barcode/Command Stack groups	40		
Using a Barcode/Command Stack	42		
Recalling/executing barcode commands in memory ...	42		
To execute steps in a command group	42		
Recalling/executing previously input barcode commands from list view	43		
How to display total hours played and total power on time			
How to display total hours played and total power on time	44		
External synchronizing function	45		

CONNECTION OF MOUSE AND KEYBOARD

A commercially available PS/2 mouse or PS/2 keyboard can be connected to this unit's mouse/keyboard connector as follows.



- 1. Turn this unit's POWER off to set it to the standby mode.**
 - 2. Connect the PS/2 *mouse or PS/2 *keyboard to this unit's MOUSE/KEYBOARD connector.**
 - 3. Turn this unit's POWER ON.**
- Connection is now complete.

If you want to use both the mouse and keyboard, connect them using a commercially available "Y" cable.

Note:

- The power rating of this MOUSE/KEYBOARD connector is no more than 100mA. Do not use a mouse or keyboard with a current drain exceeding the rating of 100mA.
- Certain commercially available PS/2 mouse models, PS/2 keyboard models and "Y" cables may not be compatible with this unit. For details, please consult PIONEER technical support.

* PS/2 is a registered trademark of IBM corporation.

PLAYER CONTROL USING A MOUSE

Mouse operation is possible by connecting a PS/2* mouse and turning power ON.

PLAYER CONTROL ICON

Pressing the mouse's left and right button simultaneously or clicking the right button while holding the left button displays the player control icons on the bottom left of the screen. When the mouse pointer is placed on a player control icon, the pointer changes from  to . While the pointer is in the form of , clicking with the left mouse button performs the same operation as the remote control unit button.


Discs Function	DVD	VIDEO CD	CD
	YES	YES	YES
	YES	YES	YES
	YES	YES	NO
	YES	YES	YES
	YES	NO	NO
	YES	YES	YES
	YES	YES	YES

Clicking the mouse's right button while  is placed on the right half  buttons of the player control icon performs the same operation as that when the  button of the remote control unit is pressed. In the same way, clicking the mouse's right button while  is placed on the left half  button of the player control icon performs the same operation as that when the  and then  button of the remote control unit is pressed.

To make the player control icons disappear, perform the same operation as for displaying them, i.e. click the mouse's right button while holding the left button.

CAUTION

While player control icons are displayed, clicking the mouse's right button cannot activate the video blackboard function. To activate the video blackboard function, make the player control icons disappear before clicking the mouse's right button. (Refer to page 18.)



ADVANCED FEATURE MENU SETTINGS

There are 13 items for setup of the DVD-V7200's original functions. Menu operation is carried out with the remote control unit.

● WEEKLY TIMER: OFF/ON

This can set the time for turning power on/off for each day of the week together with the title and chapter (or COMMAND STACK) with which playback is to be started. With this function, unattended operation is possible.

● POWER ON START: OFF/ON

This can set whether playback is to be started automatically (ON) or not (OFF) when the power is turned on.

● TITLE PLAY MODE: SINGLE/ALL

When this is set to SINGLE, playback stops after having played a title. When it is set to ALL, playback stops after having played all titles* in a disc.

* Excluding some discs with menus.

● REPEAT MODE: OFF/CHAPTER/TITLE/DISC

This item sets what is played repeatedly.

When the TITLE DISPLAY MODE is set to ALL, the DISC mode will be added.

OFF: Repeat playback is deactivated.

CHAPTER: Only a chapter is played repeatedly.

TITLE: Only a title is played repeatedly.

DISC: The entire disc is played repeatedly.

● BAUD RATE: 4800 bps/9600 bps

This sets the baud rate of the RS-232C interface. The baud rate can be selected between 4800 bps and 9600 bps.

● TRAY LOCK: OFF/ON

When this is set to ON, the disc tray is locked and cannot be opened or closed. This item helps prevent disc theft.

● BLACKBOARD LOCK: OFF/ON

Normally, clicking the mouse's right button will display the video blackboard input screen but when this is set to ON, the blackboard is locked and will not be activated when the mouse's right button is pressed.

● STILL MODE: FRAME/FIELD

Set this item to FIELD if the still image fluctuates.

● D.R.COMP.: 9 options including OFF/1 to 8 (MAX)

D.R.COMP. stands for Dynamic Range Compression. As the DVD audio has a wide dynamic range, the words may be hard to be understood through your stereo system or TV. In this case, set this item as required.

CAUTION:

D.R.COMP. affects only discs recorded in Dolby Digital (AC-3).

● MARK FRAME SQUELCH: OFF/ON

The picture will be paused at the set mark frame command (end point).

ON: Frame search is used near the end point to confirm the accuracy of the mark frame.

OFF: Although transition from playback to still picture is smooth, there is error between mark frame set value and actual still picture.

● SQUELCH DUR SEARCH: OFF/ON

To set whether a black screen is displayed or not each time search is used. (excluding frame search)

● SYNC OUT (DURING SQ): OFF/ON

ON: The video output is stopped except during playback or a menu screen.

OFF: Video is always output.

● STACK MODE OSD:ON/OFF

For ON/OFF control of OSD display during stack execute.

ADVANCED FEATURE MENU SETUP

Advanced feature menu setting is done with the remote control unit. Setup can be done either when a disc is playing, or when the player is stopped.

DISPLAYING THE MENU SCREEN

Press and hold the  button until the menu screen appears (for about 1.5 sec.).

- The menu screen is displayed.

Menu to the 1/2 screen

MENU	page 1/2
WEEKLY TIMER	OFF
POWER ON START	OFF
TITLE PLAY MODE	SINGLE
REPEAT MODE	CHAPTER
BAUD RATE	4800bps
TRAY LOCK	OFF
BLACKBOARD LOCK	OFF
STILL MODE	FRAME
▶D.R.COMP	OFF



Menu to the 2/2 screen

MENU	page 2/2
▶MARK FRAME SQUELCH	OFF
SQUELCH DUR SEARCH	OFF
SYNC OUT (DURING SQ)	OFF
STACK MODE OSD	ON

Move the ▶ (pointer) to the item you want to set with the remote control unit's  or  button and change the setting with the remote control unit's  or  button.

Menu setup is explained in detail from the next page.

CLEARING THE MENU SCREEN

Press the  button.

- The menu screen disappears.

NOTE:


When the menu screen is closed the settings will be stored in the internal memory.

If this unit's power is turned OFF while the menu setup screen is open, settings will be erased without being stored.

Pressing the remote control unit's  or  button will move the ▶ (pointer) on the left side of the setting item up or down. When the menu page 1/2 screen has a ▶ (pointer) at the very bottom part of it, pressing the remote control's  button again will change the menu to the page 2/2 screen. When the menu page 2/2 screen has a ▶ (pointer) at the very top part of it, pressing the remote control's  button again will change the menu to the 1/2 screen.


WEEKLY TIMER OPERATION

1




ON


2



3-4



5



Tip

The built-in clock is powered by a capacitor. The clock of this unit functions even when it is in the STANDBY mode, provided that the AC cord is plugged into a power outlet. If the AC cord is unplugged, the clock can continue functioning for 3 or 4 days (when the capacitor is fully charged and at 25 deg.C).

SETTING/CORRECTING THE CURRENT TIME

Set the current date and time.

1. Move the ► (pointer) to "WEEKLY TIMER" by pressing the or .

2. Press the or button and set to ON.

3. Press the .

• The Weekly Timer setting screen is displayed.

4. Press the .

• The date/time setting screen is displayed blinking.

5. Set the time of the day.

• Set figures in order of year (2 digits), month, day, day of the week, hour, minute and second.

These figures can be input in any of the following two methods.

A. Input using the numeric buttons and the NEXT

() button

B. Input using the or button and the ENTER () button

• "A" and "B" in the following description refers respectively to the two operation methods above.

Example) To set to 8:15:00, Wednesday April 29, 1998

A: Press → .

* The days of the week can be set using the following numeric buttons.

MON.: 0, TUE.: 1, WED.: 2, THU.: 3, FRI.: 4, SAT.: 5, SUN.: 6.

B: Press the or button to select 98 and press


the item to start the setting of the next set of figures (the month in this case).

Set the month, day, day of the week, hour, minute and second, and press the button to complete the setting operation.

To correct the date or time

When the setting screen appears in step 3 above, press the button so that the figures of the year start to blink. Then press the button 4 times so that the figures of hour blink, and set them with the same method as above.

WEEKLY TIMER OPERATION



SETTING THE WEEKLY TIMER

1. When the setting screen appears in step 3 on the previous page, press the or button to move ► (pointer) to the day of the week and press the button.

2. Set the power ON/OFF time.

Example 1) To turn power ON at 10:30 on Wednesday

- Move ► (pointer) to “WED” and press the ENTER button.

A: Press → → → → → → → → → → .

B: Press the or button to select 10 and press the item to start the setting of the next set of figures. Now set it to 30 and press the button twice.

- If the power OFF time is not set, the timer simply turns power ON.


Example 2): To turn power ON at 10:30 on Wednesday and turn it off at 17:45

A: Press → → → → → → → → → → → → → → .

B: Press the or button to select 10 and press the item to set the setting of the next set of figures. Set the subsequent sets of figures to 30, 17 and 45 by repeating the above.





NOTE:

It is also possible to set only the power OFF time without setting the power ON time. In this case, when power is turned ON manually, it will be turned OFF at the set time.



WEEKLY TIMER OPERATION

3



3. Set the operation to be performed at the moment timer playback starts.

1. **TITLE: Setup for playing the specified title and chapter.**

- Refer to "Playing the specified title and chapter".

2. **BARCODE COMMAND STACK: Setup for recalling the display of the barcode command stack groups from memory.**

- Refer to "Recalling the display of the barcode command stack groups from memory" on next page.
- Select one of the above with the or button, and press the .

CAUTION

- This step cannot be performed if the power ON time has not been set.
- The data is written in memory at the moment the timer setup screen is exited. The timer setup will not be stored in memory if power is turned off before or without exiting the screen.
- On a DVD disc that has been setup to start playback automatically, the setup made above will not be applied to the disc.

CLEARING THE SET TIME

With the **TIMER ON/OFF** time input screen (shown above) displayed, press the button of the remote control unit.

To clear the set time and return to the list display.

PLAYING THE SPECIFIED TITLE AND CHAPTER

- Move ► (pointer) to "1 TITLE" and press the .

Example) To begin playback with Chapter 2 of Title 6




A: Press → → → → → → .

B: Press the or button to select 06 and press the item to start the setting of the next set of figures. Now press the or to select 02 and press the .

CAUTION

- When a title and chapter are selected, playback continues after the selected chapter only when there is one or more chapter after it. Playback completes at the end of the selected title.
- If repeat playback is set in the Advanced Feature menu, the selected chapter is played first then the set repeat playback starts.
- When setting tracks on a CD or Video CD, please enter the track number in the CHAPTER in the above setting. At this time TITLE and BARCODE/COMMAND STACKS settings will not operate.

WEEKLY TIMER OPERATION



SETUP FOR RECALLING THE DISPLAY OF BARCODE/COMMAND STACK GROUPS FROM MEMORY

- Move the pointer to **2. BARCODE/COMMAND STACK** and press



Example) To recall and display Barcode/Command stack group "5"

A: Press  →  → .

B: Press the  or  button to select 005 and press the  button.

Now the timer setting is complete.

CAUTION

When a Barcode Command stack group is selected, the command stack within the group will be executed repeatedly regardless of whether the repeat mode in the Advanced Feature menu is set to ON or OFF.

SETTING THE TIMER FUNCTION TO NOT OPERATE WITH THE WEEKLY TIMER SETTING LEFT AS IS

- Move the ▶ (pointer) to **WEEKLY TIMER** on the Advanced Feature menu screen and set to OFF with the remote control unit's



button.

POWER ON START FUNCTION

1-2

MENU	page 1/2
WEEKLY TIMER	OFF
▶POWER ON START	ON
TITLE PLAY MODE	SINGLE
REPEAT MODE	CHAPTER
BAUD RATE	4800bps
TRAY LOCK	OFF
BLACKBOARD LOCK	OFF
STILL MODE	FRAME
D.R.COMP	OFF

3

Select 1

Select 2

POWER ON START	
▶1.TITLE	
▶2.BARCODE/COMMAND STACK	

POWER ON START	
▶1.TITLE	
TITLE 06 CHAPTER 02	
2.BARCODE/COMMAND STACK	

MENU	page 1/2
WEEKLY TIMER	OFF
▶POWER ON START	T06:C02
TITLE PLAY MODE	SINGLE
REPEAT MODE	CHAPTER
BAUD RATE	4800bps
TRAY LOCK	OFF
BLACKBOARD LOCK	OFF
STILL MODE	FRAME
D.R.COMP	OFF

Specify the title and chapter.

POWER ON START FUNCTION

1. Move the ► (pointer) to "POWER ON START" by pressing the or button.

2. Set it to ON by pressing the or button.

3. Press the .

- The **POWER ON START** setting screen is displayed.

1. **TITLE:** Playing the specified title and chapter.

2. **BARCODE/COMMAND STACK:** Recalling and displaying the Barcode/Command stack groups in memory.

- Select one of the above with the or button, and press the .

1. **Playing the specified title and chapter**

- Move the ► (pointer) to **1. TITLE** and press .

Example) To begin playback with Chapter 2 of Title 6


A: Press → → → → → → .

B: Press the or button to select 06 and press the item to start the setting of the next set of figures. Now press the or to select 02 and press the .

CAUTION

- When setting tracks on a CD or Video CD, please enter the track number in the CHAPTER in the above setting. At this time TITLE and BARCODE/COMMAND STACKS settings will not operate.

POWER ON START FUNCTION



Specify the Barcode/Command stack.

2. Recalling and displaying the Barcode/Command stack groups in memory

- Move the ► (pointer) to **2. BARCODE/COMMAND STACK** and press .

Example) To execute Barcode/Command stack group 5

A: Press  →  → .

B: Press the  or  button to select 005 and press the  button.

- The Advanced Feature menu setup screen is displayed again, in which the **POWER ON START** setting is shown. Now the setting of the operation to be performed at power ON is complete.

CAUTION

With a disc with which playback starts automatically, the operation may differ from the setting.

TURNING OFF THE POWER ON START FUNCTION

- On the Advanced Feature menu screen, move the ► (pointer) to **POWER ON START** with the remote control unit's  or  button and select OFF with the remote control unit's  or  button.

ADVANCED FEATURE MENU DETAILED INFORMATION

TITLE PLAY MODE SETUP

On the Advanced Feature menu screen, move the ►(pointer) to **TITLE PLAY MODE** with the remote control unit's  or  button and press the remote control unit's  or  button to select **SINGLE** or **ALL**.

TITLE PLAY MODE SINGLE

In the normal DVD player mode, playback will stop after playback of 1 title on the DVD disc.

TITLE PLAY MODE ALL

After playback of 1 title on the DVD disc, playback will continue to the next title and play all titles on the disc.

NOTE:

Some DVD discs include menus etc., and on these types of discs playback will pause while the menu screen is displayed and the above operations will not function.

REPEAT MODE SETUP

On the Advanced Feature menu screen, move the ►(pointer) to **REPEAT MODE** with the remote control unit's  or  button and press the remote control unit's  or  button to select between **OFF/CHAPTER/TITLE/DISC**.

When the TITLE DISPLAY MODE is set to ALL, the DISC mode will be added.

OFF: In the normal DVD player mode, repeat playback is deactivated.

CHAPTER: Only one chapter is played repeatedly. (DVD disc)
On a CD or V-CD one track is played repeatedly.

TITLE: Only one title is played repeatedly.

DISC: The entire disc is played repeatedly.

On a CD or V-CD the whole disc is played repeatedly when either TITLE or DISC is selected.

BAUD RATE SETUP

This function sets the baud rate of the RS-232C interface. The baud rate can be selected between 4800 bps and 9600 bps.

For setup, move the ► (pointer) to **BAUDE RATE** on the Advanced Feature menu screen using the remote control unit's  or  button, and press the remote control unit's  or  button to select between 4800bps and 9600bps.

TRAY LOCK SETUP

When this mode is set to **ON**, the tray is locked and can not be opened or closed. When a disc is loaded and the **TRAY LOCK** is set to **ON**, the disc can not be ejected until **TRAY LOCK** is set to **OFF** with the remote control unit. Use this function when you do not wish the tray to be openable by others.

For setup, move the ► (pointer) to **TRAY LOCK** on the Advanced Feature menu screen using the remote control unit's  or  button, and press the remote control unit's  or  button to select between **OFF/ON**.

BLACK BOARD LOCK SETUP

This function locks the black board input mode so that the black board screen is not displayed. Input functions other than player control functions operated with the mouse are prohibited. Use this function when an undetermined number of people are using the player and you do not want the video back board input commands etc., to be changed.

For setup, move the ► (pointer) to **BLACK BOARD** on the Advanced Feature menu screen using the remote control unit's  or  button and press the remote control unit's  or  button to select between **OFF/ON**.

STILL MODE SETUP

The paused picture of scenes with much movement may fluctuate during **STILL**. In this case, changing the **FRAME** to **FIELD** will stop the fluctuation, making the picture easier to see.

For setup, move the ► (pointer) to **BLACK BOARD** on the Advanced Feature menu screen using the remote control unit's  or  button and press the remote control unit's  or  button to select between **FRAME/FIELD**.

D.R.COMP SETUP (DYNAMIC RANGE COMPRESSION)

As the DVD audio has a wide dynamic range, words may be hard to understand through your stereo system or TV. In this case set this function as required.

There are 9 levels that can be selected: **OFF/1 to 8 (MAX)**. For setup, move the ► (pointer) to **P.R.COMP** on the Advanced Feature menu screen using the remote control unit's  or  button and press the remote control unit's  or  button to select between **OFF/1 to 8 (MAX)**.

ADVANCED FEATURE MENU DETAILED INFORMATION

MARK FRAME SQUELCH SETUP

Within mark frame input commands, the picture will be paused at mark frame (playback stop point).

When set to **ON**, frame search is used near the end point to confirm the accuracy of the mark frame.

When set to **OFF**, although the transition from playback picture to still picture will be smooth, some amount of frame error between the mark frame set value and the actual still picture may occur.

For setup, move the ► (pointer) to **MARK FRAME SQUELCH** on the Advanced Feature menu screen using the remote control unit's  or  button and press the remote control unit's  or  button to select between **OFF/ON**.

SQUELCH DUR SEARCH SETUP

ON: Screen momentarily turns black during search.

OFF: Screen does not momentarily turn black during search.

For setup, move the ► (pointer) to **SQUELCH DUR SEARCH** setup on the Advanced Feature menu screen using the remote control unit's  or  button and press the remote control unit's  or  button to select between **ON/OFF**.

SYNC OUT (DURING SQ) SETUP

This function sets whether a picture sync signal is output with video output when the player is stopped.

OFF: Video is always output and there is no loss of sync signal.

ON: There is loss of picture output at times other than playback or when menu screens are displayed.

For setup, move the ► (pointer) to **SYNC OUT (DURING SQ)** on the Advanced Feature menu screen using the remote control unit's  or  button and press the remote control unit's  or  button to select between **ON/OFF**.

STACK MODE OSD SETUP


This function controls **ON/OFF** of **OSD** displays during stack playback.

ON: **STACK OSD** is displayed on the screen when search is used during stack playback.

OFF: **STACK OSD** is not displayed.

For setup, move the ► (pointer) to **STACK MODE OSD** on the Advanced feature menu screen using the remote control unit's  or  button and press the remote control unit's  or  button to select between **ON/OFF**.

CHARACTER INPUT/PICTURE DRAWING



The video blackboard function of this unit allows you to draw characters and pictures just like on a blackboard. The drawn characters and pictures can be displayed alone or superimposed on the disc video.

OPERATION USING THE MOUSE OR KEYBOARD

Connect the PS/2 mouse or PS/2 keyboard to the mouse/keyboard connector of this unit.

Be sure to put this unit to the standby mode or unplug the power cord before connecting the mouse or keyboard to this unit.

If you want to use both the mouse and keyboard, connect them using a commercially available "Y" cable.


* The power rating for the mouse/keyboard connector of this unit is 5 V and no more than 100 mA.

Do not use a mouse or keyboard with a current drain exceeding the rating of 100 mA.

Certain PS/2 mouse models and PS/2 keyboard models may not be usable with this unit. For details, please consult PIONEER TECHNICAL SUPPORT.

ACTIVATING THE BLACKBOARD FUNCTION

1. Press the **POWER** button.
2. Click the right button anytime to display the Blackboard screen.
 - This causes forward play to stop automatically. Forward play resumes when video blackboard mode is exited.




Blackboard screen


INPUTTING CHARACTERS

1. Move the cursor to **ABC** and press click the mouse's left button.
2. Move the cursor to the position where you want to input the first character.
 - The cursor changes to the I cursor in the area where character input is possible.
3. Click the mouse's left button.
 - " _ " is displayed overlapped with the I cursor.
4. Input a character.
 - Characters can also be input from the PC keyboard provided that this is connected.
 - The PC keyboard can input characters by distinguishing the numerals, symbols and uppercase/lowercase alphabet as well as carriage returns.
5. Click the mouse's right button after completing the input.
 - The Blackboard screen is displayed again.
 - To save the characters, use the procedure in "Saving characters or pictures" on page 20.

1-3




4




Input of PIONEER

5




CHARACTER INPUT/PICTURE DRAWING




Drawing tools


1




2



3



4



USING THE DRAWING TOOLS

- Use the mouse's left button to select icon below.

 **(LINE):** Draws a straight line.

 **(BOX):** This tool can be switched by clicking to a tool for drawing a line-enclosed rectangle, solid-painted rectangle or a rectangle the outside of which is painted.

 **(ROUND):** This tool can be switched by clicking to a tool for drawing an ellipse, solid-painted ellipse or an ellipse the outside of which is painted.

 : This tool can be switched by clicking to a tool for drawing a thin, medium or thick line.

 **COLR:** Each click switches the color to Red, Blue, Green, Yellow, White, Black, Gray or Purple.

 **SAVE:** Saves the drawn picture.
(See page 20 for the saving method.)

 **UNDO:** Cancels the drawn picture. Each click cancels the last drawn picture.
Press with the mouse for more than 1 second to clear the entire drawing in the screen.

 **EXIT:** Click the mouse to exits the current screen .

NOTE

- The Direction buttons (     ) and ENTER button on the remote control unit can also be used for the above operation.
- The blackboard function will not function in a disc's menu screen.

DRAWING A PICTURE

Press the mouse's left button at the point you want to start drawing and move the cursor (without releasing the mouse button). (This operation is referred to as dragging.)

1. Select a drawing tool.

2. Move cursor to the drawing start position.

3. Drag.


- A picture is drawn as you move the cursor.

4. Release finger from the mouse.


- Draw other pictures by repeating the above.

CHARACTER INPUT/PICTURE DRAWING


1





2-4



5



6



SAVING CHARACTERS OR PICTURES

1. Click the **SAVE** button on the screen.
 - The Save screen is displayed.
2. Display the video where you want to begin displaying the object or text.
 - "IN" blinks.
 - Display the video by controlling the player control icon at the bottom left of the screen.
3. Click the **SAVE** button on the screen.
 - "OUT" starts to blink.
 - This sets the display start position.
4. Display the video where you want to stop displaying the object or text.
 - Display the video by controlling the player control icon at the bottom left of the screen.
5. Click the **AUTO DISP** button on the screen.
 - This sets the display end position.
 - The characters or pictures are saved in the player's memory.
 - The group and step where they are saved are shown.
6. Click the **EXIT** button.
 - The Blackboard screen is displayed again.

NOTE:

By saving the characters and drawing without playing a disc, the drawing can be displayed in a desired scene. (See page 23 for executing method.)

CAUTIONS:

- With a DVD, the start point (IN) and end point (OUT) can be set only within the same title.
- Should mention that video blackboard will not function in a disc's menu screen.
- The stored frame will have a ± 1 frame error.
- The Direction buttons (8, 9, 6, 3, 2, 1, 4, 7) and ENTER button on the remote control unit can also be used for the above operation.


DETAILS ON THE BLACKBOARD

RED: Red
BLU: Blue
GRN: Green
YLW: Yellow
WHT: White
BLK: Black
GRY: Gray
PUR: Purple

1: Line width fine
2: Line width medium
3: Line width thick
i: Solid painted
o: Outline only

L: Line
B: Box
R: Round

CHARACTER INPUT/PICTURE DRAWING



TO CHANGE THE DISPLAY MODE

1. Move the cursor to the line you want to change and click the left button of the mouse.
2. Move the cursor to  and click the left button of the mouse.

Indicator display on the right edge of screen

A : Displayed at the same time as the disc playback, from the set start point through the set end point.

A S : The video becomes a still image at the set start point.

- A S : The video becomes a still image immediately before the set start point.

No display: The set characters or pictures are not displayed.

Pressing the  button in this section starts drawing.

S : The video becomes the still image at the set start point but objects are not displayed.

Press the  button on the remote control unit to start picture drawing.

- * : The * mark is displayed on the top right of the screen during playback.

Pressing the  button in this section starts drawing.

- * S : The video becomes a still image, in which only the * mark is displayed, at the set start point.

Press the  button on the remote control unit to start picture drawing.

Meaning of displayed symbols

“S” stands for “Still image” and plays a still image at the IN point.

“A” stands for “Auto display”, which displays drawing in the screen set with AUTO DISP.

“*” displays only the * marking.

“-” displays a still image immediately before the start of the IN point.



PENCIL TOOL/FREEHAND DRAWING

Click the right button of the mouse in the video blackboard input screen to turn the pointer into the pencil tool. Freehand drawing is possible by holding the mouse's left button.

Clicking the right button again displays the Blackboard screen.

CAUTION:

- Pictures can be drawn using the pencil tool but they cannot be saved later.
- To change the color or line width, select  or the  tool on the Blackboard screen. (See “Drawing Tools” on page 19.)




Freehand drawing is possible by holding the mouse's left button.


GROUPING VIDEO BLACKBOARDS

Step section


Group section



Select a group



Select a step



GROUPING BLACKBOARDS

Blackboards can be registered by dividing them into groups according to the disc and title to enable selective use later.

This makes it possible to store drawn characters and pictures in positions matching the played images.

Pictures and characters comprising groups are also stored as steps. When executing the blackboards, arbitrary registered blackboard groups can be selected and displayed.

It is also possible to delete blackboards on a per-group basis.

When ▶ (pointer) appears to the left of DISPLAY or GROUP on the setup screen (refer to page 20), the group can be selected by pressing NEXT, PREV. Pressing SAVE will then enter that group.

When ▶ (pointer) appears to the left of GROUP, pressing the DEL button will cancel that groups content.

EXECUTING AN ENTIRE GROUP TO EXECUTE A GROUP

1. Press the button.

2. Press the button twice.

- The step section blinks.
- The step section should continue displaying 000.
- When the step is 000, the entire group will be executed.
- When a step is selected, only the selected step in the group will be executed.

3. Press .

4. Input the number of the group to be recalled/executed using the numeric buttons.

5. Press the button twice.

- This starts execution according to the selected blackboard.

TO EXECUTE STEPS IN A GROUP

1. Press the button.

2. Press the button twice.

3. Press if you want to switch the group.

- If you do not want to change the group, go to step 6 below.

4. Input the number of the group to be recalled/executed using the numeric buttons.

5. Press the button.

6. Input the number of the step to begin execution using the numeric buttons.

7. Press the button.


- This starts execution of the selected step in the selected group.
- The step setup is released after the step has been executed.



GROUPING VIDEO BLACKBOARDS

Select a step

Select a group




RECALLING/EXECUTING PREVIOUSLY INPUT BLACKBOARDS WHILE OBSERVING THEIR LIST

1. Press the **FUNCTION** button.
2. Press the **MEMORY RECALL** button twice.
3. Press the **FUNCTION** button and press the **DISP REPEAT** button.
• This displays a list of commands.
4. Select a group by pressing the **▶ NEXT** or **◀ PREV** button.
5. Select a step by pressing the **▶ NEXT** or **◀ PREV** button.
6. Press the **ENTER** button.

NOTE

Press the **CLEAR** button to clear the characters or pictures being displayed. However, characters and pictures that have been set with the **AUTO DISP** button cannot be cleared with the **CLEAR** button.

Example



Display of the recalled characters and pictures

Characters and pictures recalled by “Executing an entire group” are not displayed in the order they were registered but in order of the locations of the set display start points. When a character or picture is displayed while another character or picture is already displayed, the newly displayed character/picture is superimposed above the existing character/picture, and all characters/pictures are displayed until the last display end point among the set display end points.

- When pictures A and B are displayed, picture B appears after the display of picture A has ended.
- When pictures A and C are displayed, picture C appears above picture A which is already displayed, and the display of pictures A and C ends at the picture C end point.
- When pictures C and D are displayed, picture D appears above picture C which is already displayed, and the display of pictures C and D ends at the picture C end point.

INTRODUCTION

This player can be used as follows using the Barcode stack/Command stack function

- Commands in the barcode book included with the disc can be memorized in the player in advance. (Barcode stack function.)
- Barcodes can be set using the provided remote control for discs that do not have barcodes, or for commands that you want to use that are not provided with barcodes. (Command stack function.)
- The remote control can be used for recall and successive execution or step by step execution of memorized content.

CAUTION:

In the case of laser barcode compatible discs, barcodes for industrial LD use can be used as is (please check that such discs include the  mark). Use of the LB , barcode sheet for unmarked discs is not possible.

CAUTION:

The Barcode stack/Command stack function will not operate with CDs.

NOTE:

The maximum number of steps that can be memorized in the player is 300 steps including video blackboards.

BASIC USAGE

How to use the barcode stack/command stack function is indicated as follows:

- 1) **Display the barcode stack/command stack setup screen with the remote control**
⇒ Page 25
- 2) **Input the barcode with the barcode reader and transmit to player** ⇒ Page 26
 - Input can also be done with the remote control unit.
In the case of LaserBarcode compatible discs ⇒ page 30
In the case of regular DVD discs ⇒ Page 26~29
- 3) **Repeat step 2 in the desired playback order.**
- 4) **When input is finished, store in the player's memory** ⇒ Page 31
- 5) **Execution** ⇒ Page 42, 43

ADVANCED USAGE

With the barcode stack/command stack function of this unit, groups can be divided and memorized without influencing previously input commands.

This is convenient for separate memorization of contents of more than one disc, or when one player is being jointly used by many people.

To register a group separate to the already previously memorized content

1) Register a new group ⇒ Page 35

"GROUP 002" on the top right of the barcode stack/command stack input screen is the group number that will be memorized.

As the group number will be important for execution, please make a note of it so that you do not forget it.

2) Input the barcode with the barcode reader and transmit to player ⇒ Page 26

- Input can also be done with the remote control unit.
In the case of laser barcode compatible discs ⇒ Page 30
In the case of regular DVD discs ⇒ Page 26~29

3) Repeat step 2 in the desired playback order.

4) When input is finished, store in the player's memory ⇒ Page 31

5) Execution ⇒ Page 42, 43

At this time please select the group number that was noted in step 1.

NOTE:

Commands stored in the player's memory can be grouped together or divided ⇒ Page 38~41.

Please note, however, that the order of commands can not




BARCODE/COMMAND STACK SETTING

The player can store commands input using LASERBARCORD 2 and DVD barcodes. The stored commands can be recalled for either successive or step-by-step execution.



DISPLAYING THE BARCODE/COMMAND STACK SCREEN

1



BARCODE/COMMAND STACK screen

2



1. Press the button.

- “BARCODE/COMMAND” is displayed.

2. Press the button.


- The Barcode/Command Stack screen is displayed.
- If barcodes have already been input, their data are shown in the screen.
Select whether barcodes are to be input by erasing existing barcodes or by adding them to the existing barcodes.
- To input new barcodes from the beginning, select “YES” with the  or  button and press the  button.
- To add new barcodes to existing barcodes, select “NO” with the  or  button and press the  button.
- Press the  button to display the Barcode/Command Stack Input screen.
- When barcodes have not been input, the BARCODE/COMMAND STACK input screen will be displayed.

The barcode/command stack input screen appears.


- The setting procedure of this screen will be described in the subsequent pages.
- Barcode/Command Stacks can be set directly using a barcode reader (optional) or set using the remote control unit.

BARCODE/COMMAND STACK SETTING

1



2



DIRECT SETTING USING A BARCODE READER

1. Read a barcode with a barcode reader.
2. Send it to the player.

Example 1) Read "PLAY" and send it.

Example 2) Read "Play Title 8 Chapters 5 to 12 with Subtitle 3, Audio 2 and Angle 1" and send it.

SETTING USING THE REMOTE CONTROL UNIT

Five commands including Play ►, Pause ■, ◀■ Still/Step ■► and Stop ■ can be set using the remote control unit. The chapter search, chapter play, frame search and frame segment play commands can also be set using the remote control unit.


1. Press the  button.

- The TITLE number will blink and the input mode will be selected.


Example 1) To set "Play"

Press the  button.

- The Barcode/Command Stack Input screen shows "PLAY" and increments to the next Input screen.



Display when the example on the right is input



- Press the  button.**
 - The TITLE number will blink.
- Press the  button to initiate the numeral input mode.**
- Press  to select SEARCH FRAME.**
 - This item sets the frame number where playback should start.
 - Each press switches “CHAPTER” and “FRAME” alternately.
- Press  →  →  →  →  →**
 → .
 - This sets the start frame number.
 - If the operation up to the present has been performed during playback, the input start frame is searched now.
- Press  →  →  →  →  →**
 → .
 - This sets the end frame number. Now go to the next step.
- Press the  button to return to the cursor mode.**
 - If the operation in steps 4 and 5 is performed during playback, you can press  in place of specifying the frame number in steps 4 and 5 above. In this case, the frame number being played is input automatically.


- Display when the example on the right is input

- Press the  button.**
 - The TITLE number will blink.
- Press the  to initiate the numeral input mode.**
- Press  → .**
 - This sets title 5 and the frame input mode starts.
- Press  to select **SEARCH CHAPTER**.**
 - This item sets the chapter number where playback should start.
 - Each press switches “CHAPTER” and “FRAME” alternately.
- Press  → .**
 - This sets the start chapter number.
- Press  → .**
 - This sets the end chapter number.
- Press  → .**
 - This sets Subtitle 3.
- Press . (Do not press .)**
 - This sets Audio 2.
- Press . (Do not press .)**
 - This sets Angle 1. Now go to the next step.
- Press the  to return to the cursor mode.**





To play chapter 7 till the end as shown in Example 3), enter "8", obtained by adding 1 to 7, in MARK CHAPTER.



BARCODE/COMMAND STACK SETTING



Pressing the  button switches over to the following display.



Example 4) To input the command for setting Subtitle 1, Audio 2 and Angle 3

1. Press the  button.
 - The TITLE number will blink.
2. Press the  while the TITLE digits are blinking.
3. When the SUBTITLE digits start to blink, press  then .
4. When the AUDIO digit starts to blink, press .
5. When the ANGLE digit starts to blink, press .

- With a play command that specifies the start and end frames, it is not possible to set the subtitle, audio and angle simultaneously. However, by placing the subtitle, audio and angle setting command as described above before the frame section play command, the section playback can be executed with the specified setting.

The input as shown above allows to play title 3 frames 10000 to 15000 by setting Subtitle 1, Audio 2 and Angle 3.

With commands other than the frame section play command, such as the frame search, chapter search and chapter section play commands, the specified setting is valid within each command.

Example 5) To repeat "Play Title 3 frames 123000 to 129000" in Example 2

1. Perform steps 1 to 6 in Example 2.
 - The BARCODE/COMMAND STACK input screen of the next step appears.
2. Press the  button while the title number is blinking.
3. Press the  button.
 - The REPEAT indicator appears on the screen.



BARCODE/COMMAND STACK SETTING

SETTING THE SUBTITLE, AUDIO AND ANGLE

SUBTITLE

- "00" turns the screen color to the color specified in "Background color" in the GUI menu and makes the played image invisible.
- "01" to "32" displays the corresponding subtitle.
- "33" plays with Subtitle OFF.
- "34" is used to make the played image made invisible with "00" visible again.
- "99" retains the previous condition. This is used to change other setting than SUBTITLE while maintaining the SUBTITLE setting the same.
- "35" to "98" are invalid.

AUDIO

- "0" plays image with Audio OFF.
- "1" to "8" selects and plays the corresponding audio.
- "9" retains the previous condition.

ANGLE

- "1" to "8" selects and plays the corresponding angle.
- "9" retains the previous condition.
- "0" selects and plays Angle 9.

CAUTION

- When "retain the previous condition" is selected, "*" is displayed in the input screen.
- The barcode/command stack cannot be executed if a value that does not exist in the disc is input.

TO USE ONLY THE CHAPTER SEARCH OR FRAME SEARCH

In item "MARK CHAPTER" or "MARK FRAME", simply press the  button without setting anything.

A still image is displayed after search., still image is displayed after search.

TO CHANGE A VALUE DURING INPUT

Press the numeric button of the correct number (including 0).

To return to a previous setting point, press the  button.

TO CANCEL INPUT IN THE MIDDLE

Press the  button to return to the cursor mode, move the ► (pointer) to "EXIT" by pressing the  button and press the  button.



BARCODE/COMMAND STACK SETTING

SETUP OF LASERBARCODE COMPATIBLE DISCS

BC/COMMAND STACK GROUP 001: 001			
TITLE		LD	
SEARCH FRAME		01500	
MARK FRAME		01800	
VIDEO		0	
AUDIO		3	

Display when the example on the right is input

Example) Playback of "analog stereo" audio channel from frame 1500 to 1800 without video.

1. Press the button.
 - The TITLE number will blink.
2. Press the button to display LD.
 - Be sure to set the laser barcode compatible disc command to the TITLE LD display.
3. Press → → → → .
 - The start frame number is entered.
 - If the procedure up until this point has been done during playback, the start frame that was input is searched for.
4. Press → → → → .
 - The stop frame number is entered.
5. As the VIDEO number will blink, press .
 - The playback picture disappears.
6. As the AUDIO number will blink, press .
 - Audio will be entered and the next step proceeded to.
7. Press the button to return to the cursor mode.

NOTE:

Pressing the button after step 2 will select the chapter input mode. Refer to example 3 on page 27 for the input methods of SEARCH CHAPTER and MARK CHAPTER.

VIDEO, AUDIO SETUP

VIDEO:

- Inputting 1 selects normal video output.
- Inputting 0 selects the background color set on the GUI menu and cancels the playback picture.
- Inputting 9 maintains the previous mode. Input when you want to leave the VIDEO setting as is and change other settings.
- 2 to 8 are invalid.

AUDIO:

On laser barcode compatible discs, laser disc digital audio and analog audio are converted and recorded in the DVD format. Audio can be selected as follows.

- Inputting 0 selects the Audio OFF playback mode.
- Inputting 1 selects the "Analog audio 1/L" playback mode.
- Inputting 2 selects the "Analog audio 2/R" playback mode.
- Inputting 3 selects the "Analog audio" stereo mode.
- Inputting 5 selects the "Digital audio 1/L" mode.
- Inputting 6 selects the "Digital audio 2/R" mode.
- Inputting 7 selects the "Digital audio" stereo mode.
- Inputting 9 maintains the previous mode.
- 4 and 8 are invalid.

CAUTION:

When "Maintaining previous mode" is selected "*" is displayed on the input screen.



SAVING BARCODE/COMMAND STACK

BC/COMMAND STACK GROUP 001: 001

TITLE	05
SEARCH CHAPTER	03
MARK CHAPTER	08
SUBTITLE	03
AUDIO	2
ANGLE	1

►SAVE DEL INS EXIT



BC/COMMAND STACK GROUP 001: 002

TITLE	00
SEARCH FRAME	000000
MARK FRAME	000000
SUBTITLE	*
AUDIO	*
ANGLE	*

►SAVE DEL INS EXIT

The display disappears.

SAVING A BARCODE/COMMAND STACK

When the input operations shown in the example have completed till the end, the bar code stack/command stack input screen for the next step appears in a few seconds.



When this screen appears, press the or button to move ► (pointer) to SAVE and press the button.

- The display disappears and the input information is saved.

NOTES:

- The input information is not saved if ► (pointer) is moved to SAVE and the button is pressed before the bar code stack/command stack input screen for the next step appears.
- The input information is not saved if ► (pointer) is moved to EXIT and the button is pressed.

TO DELETE A PREVIOUSLY INPUT BARCODE/COMMAND STACK



TO DELETE A PREVIOUSLY INPUT BARCODE/COMMAND STACK

1. Press the button.
 - “BARCODE/COMMAND” is displayed.
2. Press the button.
 - The Barcode/Command Stack screen is displayed.
3. Select “NO” with the or button and press the button.
 - The Barcode/Command Stack Input screen is displayed when the button is pressed.
4. Press the button.
 - The list display appears.
5. Move the ▶ (pointer) to “DEL” by pressing the button.
6. Select the step to be deleted by pressing the or button.
7. Press the button.
 - The selected step is deleted and the numbers of the subsequent steps are decremented by 1.
8. Move the ▶ (pointer) to “SAVE” by pressing the button and press the button.

IMPORTANT:

Even if you have come to step 7 in the above deletion procedure, you can still abort deletion by moving the ▶ (pointer) to “EXIT” by pressing the button then pressing the button. The deletion is entered in memory when the “SAVE” operation is performed in step 8.



CORRECTING A PREVIOUSLY INPUT BARCODE/COMMAND STACK

BC/COMMAND STACK GROUP 001: 003		
TITLE		05
SEARCH CHAPTER		03
MARK CHAPTER		05
SUBTITLE		03
AUDIO		2
ANGLE		1
▶SAVE DEL INS EXIT		



BC/COMMAND STACK GROUP 001: 003		
TITLE		05
SEARCH CHAPTER		03
MARK CHAPTER		05
SUBTITLE		03
AUDIO		1
ANGLE		1
▶SAVE DEL INS EXIT		

CORRECTING A PREVIOUSLY INPUT BARCODE/COMMAND STACK

Example) To change the Audio setting of step 003 from 2 to 1

1. Press the button.
 - "BARCODE/COMMAND" is displayed.
2. Press the button.
 - The Barcode/Command Stack screen is displayed.
3. Select "NO" with the or button and press the button.
 - The Barcode/Command Stack Input screen is displayed when the button is pressed.
4. Press the button.
 - The list display appears.
5. Select "003 ▶" by pressing the or button.
6. Press the button.
 - This initiates the Barcode/Command Stack input mode.
7. Press the button to initiate the numeral input mode.
8. Press the button 4 times to select item "AUDIO".
9. Press button.
10. Press button.
 - The next step's Barcode/Command Input screen is displayed.
11. Press the button to return to the cursor mode.
12. Move the ▶ (pointer) to "SAVE" by pressing the button and press the button.

CAUTION:

To save the corrected information, move ▶ (pointer) to the last item (ANGLE in this example) by pressing the button repeatedly.


Press the button one more time to move to the page for the next step.

In this "next step", move ▶ (pointer) to SAVE and press the button to save data.

The corrected information is not saved if ▶ (pointer) is moved to SAVE and the button is pressed before the end of correction (in the middle of the step being corrected).



ADDING A STEP IN A PREVIOUSLY INPUT BARCODE/COMMAND STACK




ADDING A STEP IN A PREVIOUSLY INPUT BARCODE/COMMAND STACK

1. Perform steps 1 to 4 of “Correcting a previously input Barcode/Command Stack”.
2. Select the step where a new step is to be inserted by pressing the  or  button.
3. Move the > (pointer) to “INS” by pressing the  or  button and press the  button.
 - This inserts a new step before the selected step and the numbers of subsequent steps are incremented by 1.
4. Press the  button.
 - This initiates the Barcode/Command Stack input mode.
5. Press the  button to initiate the numeral input mode.
6. Set a step in the same way as “Setting a barcode command”.
7. Move the > (pointer) to “SAVE” by pressing the  button and press the  button.




GROUPING SOME BARCODE/COMMAND STACKS


1




2




3



4



5



GROUPING SOME BARCODE/COMMAND STACKS

Grouping of Barcode/Command Stacks



A group can be formed with several Barcode/Command Stacks, and more than one group can be formed and stored. When executing a group of commands, select a group from the stored groups and execute them either consecutively or step by step. It is also possible to divide or delete a group.

The following procedure consists of inserting a group delimiter after a group of barcode commands.


1. Press the button.
 - "BARCODE/COMMAND" is displayed.
2. Press the button.
 - The Barcode/Command Stack screen is displayed.
3. Select "NO" with the or button and press the button.
 - The Barcode/Command Stack Input screen is displayed when the button is pressed.
4. Press the button.
 - The list display appears.
 - Make sure that the ► (pointer) is located at the step immediately following the last entry.
5. Press the button.
 - The input screen for the first step of the next Barcode/Command Stack group appears.
 - The Barcode/Command Stacks of the next group can be set from here.




GROUPING SOME BARCODE/COMMAND STACKS




1



2



3



SWITCHING THE BARCODE/COMMAND STACK GROUP

1. Press the **MEMORY RECALL** button.
 - “BARCODE/COMMAND” is displayed.
2. Press the **ENTER** button.
 - The Barcode/Command Stack screen is displayed.
3. Select “NO” with the **4 T** or **6 U** button and press the **ENTER** button.
 - The Barcode Input screen is displayed when the **ENTER** button is pressed.
4. Press the **DISP REPEAT** button.
 - The list display appears.
5. Press the **L NEXT** or **K PREV** button.
 - Pressing the **L NEXT** button switches over to the next group.
 - Pressing the **K PREV** button switches over to the previous group.

DELETING A GROUP

1. Press the **MEMORY RECALL** button.
 - “BARCODE/COMMAND” is displayed.
2. Press the **ENTER** button.
 - The Barcode/Command Stack screen is displayed.
3. Select “NO” with the **4 T** or **6 U** button and press the **ENTER** button.
 - The Barcode Input screen is displayed when the **ENTER** button is pressed.

GROUPING SOME BARCODE/COMMAND STACKS

4

```
BC/COMMAND STACK GROUP 001/ 001
001 PLAY
002 03:123000-129000
003 05:03-07          03 2 1
004 ▶
005
006
007
008
▶SAVE DEL INS EXIT
```

4. Press the button.

- The list display appears.

5

```
BC/COMMAND STACK▶GROUP 001/ 001
001 PLAY
002 03:123000-129000
003 05:03-07          03 2 1
004
005
006
007
008
▶SAVE DEL INS EXIT
```

5. Select the group to be deleted by pressing the or

button.

6

```
BC/COMMAND STACK▶GROUP 001/ 001
001 PLAY
002 03:123000-129000
003 05:03-07          03 2 1
004
005
006
007
008
SAVE▶DEL INS EXIT
```

6. Move the ▶ (pointer) to “GROUP” on the first line by pressing the button.

7-8

```
BC/COMMAND STACK GROUP 001/ 001
001▶
002
003
004
005
006
007
008
SAVE▶DEL INS EXIT
```

7. Move the ▶ (pointer) to “DEL” by pressing the button.

8. Press the button.

- This deletes the selected group.

9

```
BC/COMMAND STACK GROUP 001/ 001
001▶
002
003
004
005
006
007
008
▶SAVE DEL INS EXIT
```


9. Move the ▶ (pointer) to “SAVE” by pressing the button and press the button.

IMPORTANT


Even if you have come to step 8 in the above deletion procedure, you can still abort deletion by moving the ▶ (pointer) to “EXIT” by pressing the button then pressing the button. The deletion is entered in memory when the “SAVE” operation is performed in step 9.

GROUPING SOME BARCODE/COMMAND STACKS


1




2




3



4



5



DIVIDING A PREVIOUSLY INPUT GROUP

1. Press the button.

- “BARCODE/COMMAND” is displayed.

2. Press the button.

- The Barcode/Command Stack screen is displayed.

3. Select “NO” with the or button and press the button.

- The Barcode/Command Stack Input screen is displayed when the button is pressed.

4. Press the button.

- The list display appears.

5. Select the step where the existing group is to be divided by pressing the or button.

- Move the ▶ (pointer) the first step of the group created by division.



GROUPING SOME BARCODE/COMMAND STACKS

6

```
BC/COMMAND STACK GROUP 001/ 001
001 PLAY
002 ►03:123000-129000
003 05:03-07          03 2 1
004
005
006
007
008
SAVE DEL ►INS EXIT
```

6. Move the ► (pointer) to “INS” by pressing the  or  button.

7

```
BC/COMMAND STACK GROUP 001/ 001
001 PLAY
002 ►
003 03:123000-129000
004 05:03-07          03 2 1
005
006
007
008
SAVE DEL ►INS EXIT
```

7. Press the  button.

- This inserts a vacant step before the selected step and the numbers of subsequent steps are incremented by 1.

8

```
BC/COMMAND STACK GROUP 002: 001

TITLE          03
SEARCH FRAME 123000
MARK   FRAME 129000

►SAVE DEL INS EXIT
```

8. Press the  button.

- This divides the existing group at the vacant step.
- A new group is created. The Barcode/Command Stack Input screen of the first step of the newly created group is displayed.

9

```
BC/COMMAND STACK GROUP 002: 001

TITLE          03
SEARCH FRAME 123000
MARK   FRAME 129000

►SAVE DEL INS EXIT
```


9. Move the ► (pointer) to “SAVE” by pressing the  button and press the  button.

IMPORTANT


Even if you have come to step 8 in the above group procedure, you can still abort group by moving the ► (pointer) to “EXIT” by pressing the  button then pressing the  button. The group is entered in memory when the “SAVE” operation is performed in step 9.

GROUPING SOME BARCODE/COMMAND STACKS


1




2




3



4



5



JOINING TWO BARCODE/COMMAND STACK GROUPS

1. Press the button.

- “BARCODE/COMMAND” is displayed.

2. Press the button.

- The Barcode/Command Stack screen is displayed.

3. Select “NO” with the or button and press the button.

- The Barcode/Command Stack Input screen is displayed when the button is pressed.

4. Press the button.

- The list display of the last group that was input is displayed.

5. Change the group with the button.

- Move the ▶ (pointer) to the next step of the previously input number with the or button. This becomes the division point.



GROUPING SOME BARCODE/COMMAND STACKS

6

```
BC/COMMAND STACK GROUP 003/ 004
001 02:000150-002050
002 06:22-23          * * *
003▶
004
005
006
007
008
SAVE▶DEL  INS  EXIT
```

6. Move the ▶ (pointer) to “DEL” by pressing the  button.

7

```
BC/COMMAND STACK GROUP 003/ 003
001 02:000150-002050
002 06:22-23          * * *
003▶PLAY
004 03:123000-129000
005 05:03-07          03 2 1
006
007
008
SAVE▶DEL  INS  EXIT
```

7. Press the  button.

- This deletes the group delimiter and joins the current group with the next group to it.
- The numbers of the groups after the current group are decremented by 1.

8

```
BC/COMMAND STACK GROUP 003/ 003
001 02:000150-002050
002 06:22-23          * * *
003▶PLAY
004 03:123000-129000
005 05:03-07          03 2 1
006
007
008
▶SAVE DEL  INS  EXIT
```


8. Move the ▶ (pointer) to “SAVE” by pressing the  button and press the  button.

IMPORTANT

Even if you have come to step 7 in the above group Joining, you can still abort group by moving the ▶ (pointer) to “EXIT” by pressing the  button then pressing the  button. The group is entered in memory when the SAVE” operation is performed in step 8.


USING A BARCODE/COMAND STACK

Switch the command group.



Recall screen

Switch the command step.



Recall screen

RECALLING/EXECUTING BARCODE COMMANDS IN MEMORY

To execute a barcode command group:

Place the disc containing commands on the disc tray.

1. Press the  button.
2. Press the  button.
3. Press the  button.
4. Input the number of the command group to be recalled/ executed using the numeric buttons.
5. Press the  button twice.
 - This recalls and executes the selected group.

TO EXECUTE STEPS IN A COMMAND GROUP


1. Press the  button.
2. Press the  button.
3. Press the  button.
4. Input the number of the command group to be recalled/ executed using the numeric buttons.
5. Press the  button.
 - To re-enter the group number, press the  button.
6. Input the number of the step to begin execution using the numeric buttons.
7. Press the  button.
 - This recalls and executes the selected and subsequent steps in the selected group.

NOTES:

- Pressing the  button while the FUNCTION indicator is lit repeats the execution of the set command.
- If you press the  button in place of the  button in step 6 above, command steps will be executed step by step. After every step has been executed, press the  button to advance to the next step. Pressing the  button allows you to return to the previous step.



USING A BARCODE/COMAND STACK



BARCODE/COMMAND STACK screen

RECALLING/EXECUTING PREVIOUSLY INPUT BARCODE COMMANDS FROM THE LIST VIEW

1. Press the button.

2. Press the button.

3. Press the button.

- The button is defeated unless the function mode is switched off.

4. Press the button.

- This displays a list of commands.

5. Select a group by pressing the or button.

- Select the command group containing the command(s) to be executed.

6. Select a step by pressing the or button.

- Select the command step to begin execution with. If the command step number is left to "001" in this step, the commands in the entire command group will be executed.

7. Press the or button.

- Pressing the button starts consecutive execution.
- Pressing the button starts step-by-step execution.

Some titles may not be able to be recalled and executed.

Example)

The search command cannot be executed with a title that does not show the chapter, time and similar information on the screen or with a disc that is not permitted to use the search function.


HOW TO DISPLAY TOTAL HOURS PLAYED AND TOTAL POWER ON TIME

This unit is capable of displaying the total play time and power ON time as the working condition and maintenance timing information.

The play time and power ON time can be displayed as described below.

1. Press and hold the DISPLAY button on the front panel of the main unit before turning power ON, and press the POWER button.

2. The screen shows the following:



Power ON time, which is 105 hours 46 minutes in this example.

Total play time, which is 78 hours 13 minutes in this example.

CAUTION

As the time is measured by the CPU clock, the information includes an error of up to 2%.

3. When an operation (playback from the remote, for example) is performed, the time information display disappears and normal operation starts.


EXTERNAL SYNCHRONIZING FUNCTION

Through external input of a synchronization signal (black burst), video output signals can be synchronized with external signals on the DVD-V7200. (During DVD disc playback.)

Through the use of this function, video switch timing can be matched, and switching can be done without causing picture disturbance on the TV without the need for such devices as a TBC (Time Base Collector).

Synchronized use of 2 or more players

- Make sure that the terminator switch is ON on the terminal player and OFF on the other players.
- When applying synchronization to one player, set the terminator switch to ON.



Sync accuracy $\pm 1H$ for input synchronization signal (During DVD disc playback)

NOTE:

Externally synchronizing 2 or more DVD-V7200 players, simultaneously starting video, and obtaining sync at the frame position for playback is not possible with this player.

Because of timing of reception of the STILL to PLAY command and DVD disc content, an unevenness of approximately 2 frames may occur.

Should this product require service in the U.S.A. and you wish to locate the nearest Pioneer Authorized Independent Service Company, or if you wish to purchase replacement parts, operating instructions, service manuals, or accessories, please call the number shown below.

1 – 8 0 0 – 8 7 2 – 4 1 5 9

Please do not ship your product to Pioneer without first calling the Customer Service Department at the above listed number for assistance.

PIONEER ELECTRONICS SERVICE, INC.
CUSTOMER SUPPORT DIVISION
P.O. BOX 1760, LONG BEACH,
CA 90801-1760, U.S.A.

For warranty information please see the Limited Warranty sheet included with your product.

Should this product require service in Canada, please contact a Pioneer authorized dealer in Canada to locate the nearest Pioneer Authorized Service Company.

Alternatively, please contact or ship your defective product freight prepaid to one of the following Factory Service locations closest to you:

Pioneer Electronics of Canada, Inc.

Factory Service East
300 Allstate Parkway
Markham, ON L3R 0P2
(905) 479-4411

Factory Service West
13911 Bridgeport Road
Richmond, BC V6V 1J6
(604) 278-1014

For warranty information please see the Limited Warranty sheet included with your product.

Si ce produit doit être réparé au Canada, veuillez vous adresser à un distributeur autorisé Pioneer au Canada pour obtenir le nom de la société de service autorisée Pioneer la plus près de chez vous. Ou encore, veuillez communiquer avec le centre de service en usine Pioneer le plus près de chez vous ou faire parvenir l'article défectueux, port payé, à ce centre.

Pioneer électroniques du Canada, Inc.

Service en usine - Est
300 Allstate Parkway
Markham (Ontario) L3R 0P2
(905) 479-4411

Service en usine - Ouest
13911 Bridgeport Road
Richmond (C.-B.) V6V 1J6
(604) 278-1014

Pour obtenir des renseignements sur la garantie, veuillez vous reporter au feuillet sur la Garantie Limitée qui accompagne le produit.

Published by Pioneer Electronic Corporation.
Copyright © 1998 Pioneer Electronic Corporation.
All rights reserved.

PIONEER ELECTRONIC CORPORATION

4-1, Meguro 1-Chome, Meguro-ku, Tokyo 153-8654, Japan

PIONEER NEW MEDIA TECHNOLOGIES, INC.

2265 East 220th Street, Long Beach, CA 90810, U.S.A. TEL: 310-952-2111

PIONEER ELECTRONICS [USA] INC. P.O. BOX 1540, Long Beach, California 90801-1540

PIONEER ELECTRONICS OF CANADA, INC. 300 Allstate Parkway, Markham, Ontario L3R 0P2, Canada

PIONEER ELECTRONIC [EUROPE] N.V. Haven 1087, Keetberglaan 1, 9120 Melsele, Belgium TEL: 03/570.05.11

PIONEER ELECTRONICS AUSTRALIA PTY. LTD. 178-184 Boundary Road, Braeside, Victoria 3195, Australia, TEL: [03] 9586-6300

PIONEER ELECTRONICS DE MEXICO S.A. DE C.V. San Lorenzo Num 1009 3er piso Desp. 302 Col. Del Valle, Mexico D.F. C.P. 03100 TEL: 5-688-52-90